




nifty

**ADVANCED
ACCESS PLATFORMS**

Heightrider

Operating & Safety Instructions

**MODEL HR21 SERIES
MK2**



Manufactured by:

Niftylift Limited

Chalkdell Drive
Shenley Wood
Milton Keynes
MK5 6GF
England

niftylift.com
info@niftylift.com



M50541/03

www.niftylift.com
e-mail: info@niftylift.com
Tel: +44 (0)1908 223456
Fax: +44 (0)1908 312733

HR21 MK2 EMERGENCY PROCEDURES

Emergency Stop

- 1) Push in red emergency stop to shut down all machine movement.
- 2) Release both emergency stops to restore normal controls.

Recovery from Base Controls

If normal controls are available (Fastest recovery time):

- 1) Switch to base, press green button and operate desired function lever(s).

If normal controls are not available:

- 2) Locate manual hand pump under control side canopy.
- 3) Attach supplied handle to hand pump.
- 4) Move and hold desired boom function lever in required direction.
- 5) Pump hand pump to activate selected function.
- 6) Release lever and stop pumping to halt machine movement.
- 7) If the cage has contacted a fixed object and cage overload has disabled the machine, move machine slightly using steps 2-6. The overload alarm and visual warning will cease once normal controls are available.
- 8) If normal controls are still not available, continue pumping to lower machine manually.

Recovery from Cage Controls

- 1) Press white override button situated on the cage console.
If engine is running, it will stop. Override mode is for booms only and will not operate drive.
- 2) Activate a single desired function paddle.
(Note: Multiple boom function is not available in override mode).
- 3) If the cage has contacted a fixed object and cage overload has disabled the machine, move machine slightly using steps 1-2. The overload alarm and visual warning will cease and normal controls are available.
- 4) Restart engine with selector switch.
- 5) Use normal controls if available for fastest recovery time.
Press green button or footswitch and operate desired function lever(s).
- 6) If normal controls are not available, continue using override button to lower machine using auxiliary power.

SiOPS

If white button is flashing (SiOPS is active and cage is overloaded):

- 1) Follow procedure described in 'Recovery from Cage Controls' until green button flashes or normal operation is restored.

If green button is flashing (SiOPS is active):

- 2) Press flashing green button and operate cage controls to manoeuvre machine to a safe position.

To reset footswitch and normal controls:

- 1) Release load from front of console.
- 2) Ensure cage controls are in neutral position and clear of objects.
- 3) Raise foot clear of footswitch then lower foot onto footswitch to reactivate.

Note: If footswitch is not reset within **15 seconds**, then blue beacon on underside of cage will flash and a warning announcement will sound until footswitch is reset as described.

For further information on all controls refer to Sections 4.2 and 4.3.

Emergency lowering instructions vary between different types of Mobile Elevating Work Platform. Niftylift recommend that operators, site-safety personnel, and ground workers are trained in and practise these machine-specific procedures.

Table of Contents

1	Introduction and General Information	2
1.1	FOREWORD.....	2
1.2	SCOPE.....	3
1.3	INTRODUCING THE HEIGHT RIDER SELF-PROPELLED (SP) SERIES.....	3
1.4	GENERAL SPECIFICATION	4
1.5	IDENTIFICATION (UK PLATE)	5
1.6	EC DECLARATION OF CONFORMITY (Typical)	7
2	Safety	8
2.1	MANDATORY PRECAUTIONS	8
2.2	ENVIRONMENTAL LIMITATIONS.....	12
2.3	NOISE AND VIBRATION	12
2.4	TEST REPORT	13
3	Preparation and Inspection	14
3.1	UNPACKING	14
3.2	PREPARATION FOR USE	14
3.3	PRE-OPERATIONAL SAFETY CHECK SCHEDULES	15
3.4	PLACARD, DECALS & INSTALLATION (UK SPEC)	18
3.5	TORQUE REQUIREMENTS	21
4	Operation	22
4.1	CONTROL CIRCUIT COMPONENTS	22
4.2	GROUND CONTROL OPERATION.....	24
4.3	PLATFORM CONTROL OPERATION.....	27
4.4	DRIVING CONTROLS	37
4.5	CAGE WEIGH SYSTEM.....	38
4.6	BATTERIES AND CHARGING.....	39
4.7	TRANSPORTING, TOWING, CRANEAGE, STORAGE AND SETTING TO WORK	42
5	Emergency Controls	46
5.1	GENERAL.....	46
5.2	IN THE EVENT OF AN INCAPACITATED OPERATOR.....	46
5.3	IN THE EVENT OF MACHINE FAILURE	46
5.4	INCIDENT NOTIFICATION.....	46
6	Responsibilities	47
6.1	CHANGES IN OWNERSHIP	47
6.2	MANUAL OF RESPONSIBILITIES (USA only).....	47
6.3	INSPECTION/SERVICE/PRE-HIRE CHECK LIST	48
Appendix A		51
Appendix B		56

1 Introduction and General Information

1.1 FOREWORD

The purpose of these manuals is to provide the customer with appropriate safety operating and maintenance instructions essential for proper machine operation.

All information in these manuals should be **READ** and fully **UNDERSTOOD** before any attempt is made to operate the machine. **THESE MANUALS ARE VERY IMPORTANT TOOLS** - Keep them with the machine at all times.

The manufacturer has no direct control over machine application and use, therefore conformance with good safety practices is the responsibility of the user and his operating personnel.

All information in these manuals is based on the use of the machine under proper operating conditions. Alteration and/or modification of the machine are strictly forbidden.

One of the most important facts to remember is that any equipment is only as safe as those who operate it.

DANGER, WARNING, CAUTION, IMPORTANT, INSTRUCTIONS AND NOTICE

Any place these topics may appear, either in this manual or on the machine, they are defined as follows:

DANGER: If not correctly followed there is a high probability of serious injury or death to personnel.

WARNING OR CAUTION: If not correctly followed there is some possibility of serious injury or death to personnel.



THE '**SAFETY ALERT**' SYMBOL IS USED TO CALL ATTENTION TO POTENTIAL HAZARDS THAT MAY LEAD TO SERIOUS INJURY OR DEATH, IF IGNORED.

IMPORTANT AND INSTRUCTIONS: Denotes procedures essential to safe operation and prevention of damage to or destruction of the machine.

NOTICE: Indicates general safety rules and/or procedures relating to the machine.

It is the owner's/user's responsibility to know and comply with all applicable rules, regulations, laws, codes and any other requirements applicable to the safe use of this equipment.

1.2 SCOPE

These operating instructions contain all the necessary information required to allow the safe operation of any Niftylift Height Rider 21 (SP64 in the USA), powered by diesel (D) and DC electric (E).

For further technical information, circuit diagrams and specific instructions for all maintenance which may need to be carried out by specialist trained personnel, see the associated Workshop and Parts manual for your model of Niftylift Height Rider.

1.3 INTRODUCING THE HEIGHT RIDER SELF-PROPELLED (SP) SERIES

Please note at the time of going to press all information, illustrations, details and descriptions contained herein are valid. Niftylift reserves the right to change, modify or improve its products without any obligations to install them on previously manufactured machines.

If, after reading this manual you require further information, please do not hesitate to contact us.

Niftylift Ltd, Chalkdell Drive, Shenley Wood, Milton Keynes MK5 6GF, Great Britain
Tel: +44 (0) 1908 223456 Fax: +44 (0) 1908 312733

Niftylift Inc, 1525 S. Buncombe Road, Greer, SC 29651 USA
Tel: +01 864 968 8881 Fax: +01 864 968 8836

Nifty Pty Ltd, 11 Kennington Drive, Tomago, NSW 2322, Australia
Tel: +61 (0) 2 4964 9765 Fax: +61 (0) 2 4964 9714

Driven from the platform, the Niftylift Height Rider 21 (SP64) is an extremely versatile articulated boom platform of unique and simple design. The HR21 can place two men and their tools at a height of 20.8m (68ft 2in) or an outreach of 13.0m (42ft 8in).

The booms are mounted via a 355⁰ powered swing mechanism onto a compact narrow base with a tight turning circle that ensures excellent manoeuvrability and maximum efficiency.

High traction tyres and powerful hydraulic wheel motors give unsurpassed performance with the option of fast drive speed when the booms are in the stowed position. Automatic braking and audible alarms activated by a four degree tilt sensor help to prevent the operator from working on unsafe terrain whilst elevated.

A digital control system gives smooth, reliable movement of the platform and maximum reliability in the harshest environments.

Models include the following:

D: - DIESEL

HYBRID - (DIESEL & BATTERY)

Operating & Safety Instructions**1.4 GENERAL SPECIFICATION**


FEATURE	HR21 4x4
MAXIMUM HEIGHT - WORKING	20.8m 68ft 2in
MAXIMUM HEIGHT - PLATFORM	18.8m 61ft 8in
MAXIMUM OUTREACH	13.0m 42ft 8in
MAXIMUM HEIGHT – STOWED	2.18m 7ft 2in
MAXIMUM WIDTH	2.27m 7ft 5in
MAXIMUM LENGTH – STOWED	6.62m 21ft 8in
MAXIMUM LENGTH - TRANSIT	5.47m 17ft 11in
PLATFORM CAPACITY - Europe	250kg (550lbs)
WHEELBASE	2.30m 7ft 6in
TURNING RADIUS – OUTSIDE	3.89m 12ft 9in
TURRET ROTATION	355°
TURRET TAIL SWING	0.45m 1ft 6in
TRAVEL SPEED	0 – 6.0kph 0 – 3.7mph
PLATFORM SIZE	1.80m x 0.85m 5ft 11in x 2ft 9in
HYDRAULIC PRESSURE	350bar
TYRES	Solid
GRADEABILITY	45%
MINIMUM VEHICLE WEIGHT	6,640kg 14,639lb
MAXIMUM GROUND PRESSURE	0.1122kN/cm ² 23,455lb/ft ²
POINT LOAD	40.6kN
MAXIMUM ALLOWABLE INCLINATION	4.0°
POWER SOURCE	DE (Diesel & Battery) - Kubota D902 engine and 8 x 6v 390 AH batteries D (Diesel) Perkins 403D engine
FUEL TANK CAPACITY	42 Litres 11.1 US Gallons
SOUND POWER LEVEL SOUND PRESSURE LEVEL Base Controls Cage Controls	105dBA 76dBA 78dBA

1.5 IDENTIFICATION (UK PLATE)

nifty			
NIFTYLIFT LTD. RINGLE DRIVE, STONEBRIDGE MILTON KEYNES MK13 0ER ENGLAND TEL 01908 223456 : FAX 01908 312733 e-mail : info@niftylift.com			
SERIAL No			
TYPE			
YEAR OF MANUFACTURE			
WEIGHT			kg
RATED LOAD	PERSONS	+	kg
MAXIMUM SAFE WORKING LOAD			kg
MAXIMUM PULL			N
MAXIMUM WIND SPEED			m/s
MAX. ALLOWABLE INCLINATION			Deg.
MAXIMUM HYDRAULIC PRESSURE			bar
MAXIMUM VOLTAGE			V
AMPS			A
ELEC. CCT D	ISSUE		
HYD. CCT D	ISSUE		
P10205			

This manufacturer's plate is attached to the chassis on each machine at the time of manufacture on every Niftylift. Please ensure all sections have been stamped and are legible.

1.5a IDENTIFICATION (USA PLATE)

	
NIFTYLIFT LTD. RINGLE DRIVE, STONEBRIDGE MILTON KEYNES MK13 0ER GREAT BRITAIN TEL (01144) 1908 223456 : FAX (01144) 1908 312733 e-mail : info@niftylift.com	
THIS WORK PLATFORM COMPLIES WITH ANSI STANDARD A 92-	
MODEL	
SERIAL NO	
YEAR OF MANUFACTURE	
CAPACITY RATING	LBS
PLATFORM HEIGHT	FEET
GROSS WEIGHT	LBS
MAXIMUM HYDRAULIC PRESSURE	PSI
MAXIMUM VOLTAGE	V
AMPS	A
ELEC. CCT D	ISSUE
HYD. CCT D	ISSUE
P11497	

This manufacturer's plate is attached to the chassis on each machine at the time of manufacture on every Niftylift. Please ensure all sections have been stamped and are legible.

1.6 EC DECLARATION OF CONFORMITY (Typical)



EC DECLARATION OF CONFORMITY

MANUFACTURER
AND PERSON
RESPONSIBLE FOR
DOCUMENTATION:

NIFTYLIFT LTD
MARTIN CROSS

ADDRESS:

CHALKDELL DRIVE,
SHENLEY WOOD,
MILTON KEYNES,
MK5 6GF,
ENGLAND.

MACHINE TYPE:

MOBILE ELEVATING WORK PLATFORM

MODEL TYPE:

SERIAL NUMBER:

** /*****

APPROVED BY:

NIFTYLIFT LTD
CHALKDELL DRIVE,
SHENLEY WOOD,
MILTON KEYNES,
MK5 6GF,
ENGLAND.

TECHNICAL FILE NUMBER:

APPLICABLE STANDARDS:

EN 280:2013
DIN EN 60204-1, 2006/42/EC

We hereby declare that the above mentioned machine conforms with the requirements of the Machinery Directive, 2006/42/EC and EMC Directive 2004/108/EC.

SIGNED:

DATE: 19/10/2015

NAME: Steven Redding

POSITION: Development Director

NOTE:

THIS DECLARATION CONFORMS WITH THE REQUIREMENTS OF ANNEX II-1.A OF THE COUNCIL DIRECTIVE 2006/42/EC ANY MODIFICATIONS TO THE ABOVE MENTIONED MACHINE WILL INVALIDATE THIS DECLARATION, AND THE MACHINE'S APPROVAL.

2 Safety

2.1 MANDATORY PRECAUTIONS

When operating the Niftylift, your safety is of utmost concern. In order to fully appreciate all aspects of the machine's operation it should be ensured that each operator has **READ** and fully **UNDERSTOOD** the relevant manual covering machine use, maintenance and servicing. If any doubts exist concerning any points covered in this manual, contact your local dealer or Niftylift Ltd.

Before using any Niftylift, thoroughly inspect the machine for damage or deformation to all major components. Likewise, check the control systems for hydraulic leaks, damaged hoses, cable faults or loose covers to electrical components. At no time should damaged or faulty equipment be used - Correct all defects before putting the platform to work. If in doubt, contact your local dealer or Niftylift Ltd (see front cover for address).



THE MANUFACTURER HAS NO DIRECT CONTROL OVER THE MACHINE APPLICATION AND USE. THEREFORE CONFORMITY WITH GOOD SAFETY PRACTICES IS THE RESPONSIBILITY OF THE USER AND HIS OPERATING PERSONNEL. FAILURE TO UNDERSTAND AND FOLLOW ALL SAFETY RULES COULD RESULT IN SERIOUS INJURY OR DEATH.


- 2.1.1** Only trained persons are permitted to operate the Niftylift.
- 2.1.2** Always operate the Niftylift in accordance with these model-specific Operating & Safety Instructions.
- 2.1.3** Before use each day and at the beginning of each shift the Niftylift shall be given a visual inspection and functional test including, but not limited to, operating and emergency controls, safety devices, personal protective clothing, including fall protection, air, hydraulic and fuel system leaks, cables and wiring harness, loose or missing parts, tyres and wheels, placards, warnings, control markings and Operating and Safety Manuals, guards and guard rail systems and all other items specified by the manufacturer.
- 2.1.4** Any problems or malfunctions that affect operational safety must be repaired prior to use of the platform, with specific regard to any safety components refer to the Parts Manual for part numbers and details. If in doubt, contact Niftylift Ltd (Details on page 3). **Ensure wheels are chocked before carrying out any maintenance that involves gearbox disengagement as described in Section 4.7.2**
- 2.1.5** Always ensure that all warning labels, instructions, placards, control markings and Operating & Safety Manuals are intact and clearly legible. If replacements are required contact your local dealer or Niftylift. **Always obey the safety and operating instructions on labels.**
- 2.1.6** Do not alter, modify, or disable in any way the controls, safety devices, interlocks, or any other part of the machine.
- 2.1.7** The user must ensure that, prior to and during use, the working area and transport route is free from possible hazards such as, but not limited to, uneven ground drop-offs, holes, bumps, obstructions, debris, floor and overhead obstructions, high voltage conductors, wind and weather, unauthorised persons and any other possibly hazardous conditions.

- 2.1.8** This machine contains several hazardous substances such as but not limited to: Battery acid, Hydraulic Fluid, Engine Coolant, Antifreeze, Diesel Fuel, Petrol, Engine Oil, Grease, Gasoline.
- 2.1.9** Covers and canopies should remain closed when the machine is in operation. Only trained personnel should carry out maintenance on the machine, ensuring at all times they protect themselves from electrical, heat and mechanical hazards.
- 2.1.10** Never exceed the maximum platform capacity, as indicated on the decals and machine serial plate.
- 2.1.11** Only operate the Niftylift on a firm, level surface.
- 2.1.12** Never position any part of the Niftylift inside the **Minimum approach distances** (MAD) to above-ground electrical conductors as listed in the table below. (Reference ISO 18893:2014).

Voltage range (kV)	MAD (m)
<0.7	1
≥0.7 to 7	1.2
>7 to 50	3
>50 to 220	4
>220 to 500	5
>500 to 750	10
>750 to 1000	13
>1000 to 1250	16

**THIS MACHINE IS NOT INSULATED.**

If in doubt, contact the local appropriate governing authority.

- 2.1.13** On entering the platform ensure that the drop down entry bar is closed afterwards.
- 2.1.14** Use of an approved full-body harness and short lanyard, hard hat and appropriate safety clothing is mandatory. Fasten harness to designated harness securing points within the platform and do not remove until leaving the platform whilst in the stowed position. **Note**; if working next to or over water, the risk of injury from either falling or drowning must be assessed. Then the decision can be made if it is appropriate to wear a harness.
- 2.1.15**  Always remain standing within the platform. Do not attempt to increase your height or reach by standing and/or climbing on the platform guard rails or any other object. **KEEP YOUR FEET ON THE PLATFORM FLOOR.** Do not sit, stand or climb on the guard rail, mid rail or boom linkage. Use of planks, ladders or any other devices on the Niftylift for achieving additional height or reach shall be prohibited.
- 2.1.16** Do not use the platform levelling system to artificially increase the outreach of the platform. Never use boards or ladders in the platform to achieve the same result.
- 2.1.17** Do not use the platform to lift overhanging or bulky items that may exceed the maximum capacity or carry objects that may increase the wind loading on the platform. (e.g. Notice boards etc.)

Operating & Safety Instructions

- 2.1.18** The Niftylift shall not be operated from a position on trucks, trailers, railway cars, floating vessels, scaffolds or similar equipment unless the application is approved in writing by Niftylift Ltd in Great Britain.
- 2.1.19** Always check that the area below and around the platform is clear of personnel and obstructions before lowering or slewing. Care should be taken when slewing out into areas where there may be passing traffic. Use barriers to control traffic flow or prevent access to the machine.
- 2.1.20** Stunt driving and horseplay, on or around the Niftylift, is not permitted.
- 2.1.21** When other moving equipment or vehicles are present, special precautions shall be taken to comply with local ordinances or safety standards established for the work place. Warnings, such as but not limited to, flags, roped off areas, flashing lights and barricades shall be used.
- 2.1.22** Before and during driving while the platform is elevated, the operator shall maintain a clear view of the path of travel, maintain a safe distance from obstacles, debris, drop offs, holes, depressions, ramps and other hazards to ensure safe elevated travel. Maintain a safe distance from overhead obstacles.
- 2.1.23** The aerial platform is not equipped for or intended for use on a public highway.
- 2.1.24** Under all travel conditions the operator shall limit travel speed according to conditions of ground surface, congestion, visibility, slope, location of personnel and other factors causing hazards of collision or injury to personnel.
- 2.1.25** The aerial platform shall not be driven on grades, side slopes or ramps exceeding those for which the aerial platform is rated by the manufacturer.
- 2.1.26** It shall be the responsibility of the user to determine the hazard classification of any particular atmosphere or location. Aerial platforms operated in hazardous locations shall be approved and suitable for the duty. (See ANSI/NFPA 505 where applicable).
- 2.1.27** The operator shall immediately report to his supervisor any potentially hazardous location(s) (environment) which become evident during operation.
- 2.1.28** If an operator encounters any suspected malfunction of the Niftylift or any hazard or potentially unsafe condition relating to capacity, intended use or safe operation, they shall cease operation of the Niftylift and request further information as to safe operation from their management, or owner, dealer or manufacturer before further operation of the Niftylift.
- 2.1.29** The operator shall immediately report to their superior any problems or malfunctions of the Niftylift, which becomes evident during operation. Any problems or malfunctions that affect the safety of operation shall be repaired prior to continued use.
- 2.1.30** The boom and platform of the Niftylift shall not be used to jack the wheels off the ground.
- 2.1.31** The Niftylift shall not be used as a crane.
- 2.1.32** The Niftylift shall not be positioned against another object to steady the platform.
- 2.1.33** Care should be taken to prevent rope, electrical cords and hoses from becoming entangled in the aerial platform.
- 2.1.34** Batteries shall be recharged in a well-ventilated area free of flame, sparks or other hazards (e.g. do not smoke near the machine), which may cause explosion. Highly explosive hydrogen gas is produced during the charging process.

- 2.1.35** If the platform or elevating assembly becomes caught, snagged or otherwise prevented from normal motion by adjacent structure or other obstacles, such that control reversal does not free the platform, all personnel shall be removed from the platform safely before attempts are made to free the platform using ground controls.

2.1.36



When the machine is not in use always stow the booms correctly. **NEVER LEAVE THE KEY IN THE MACHINE**, if it is to be left for any period of time. Use wheel chocks if leaving on an incline.

2.1.37

The engine must be shut down while fuel tanks are being filled. Fuelling must be done in a well-ventilated area free of flame, sparks or any other hazard that may cause fire or explosion. **PETROL (GASOLINE) AND DIESEL FUELS ARE FLAMMABLE.**

2.1.38



NEVER START THE NIFTYLIFT IF YOU SMELL PETROL (GASOLINE), LIQUID PROPANE OR DIESEL FUEL. THESE FUELS ARE HIGHLY FLAMMABLE

2.1.39

The operator must ensure that engine powered machines are used in a well-ventilated area to minimise the risk of carbon monoxide poisoning.

2.1.40

The operator shall implement means provided to protect against use by unauthorised persons.

2.1.41

Never remove anything that may affect the stability of the machine such as, but not limited to, batteries, covers, engines, tyres or ballast.

2.1.42


The operator must ensure that the controls are not obstructed (e.g. by tools or equipment) and **clear access to the Emergency Stop** is available at all times.

2.1.43

All persons in the cage must take suitable precautions to prevent items falling or being ejected from the cage. E.g. Tethering tools to the machine or operator if practical and an assessment of any resulting risks is acceptable.

2.1.44

Hydraulic oil escaping under pressure can penetrate the skin and cause **serious injury**. Do not allow hydraulic oil to squirt or spray. **Seek immediate medical attention in the event of hydraulic oil penetrating the skin.** Wear chemical-resistant protective gloves and suitable eye protection when handling hydraulic oil. Relieve system pressure before removing any hydraulic connections, undo fittings slowly to make sure there is no residual pressure. If pressure is detected, allow it to be released slowly before completely removing hose. Fluid leaks may not be visible to the naked eye. Use a piece of cardboard to check for leaks, not your hand. **Never** install hydraulic lines or components that are damaged.



2.1.45

The HR21 MK2 has been tested in a UKAS accredited electromagnetic compatibility (EMC) chamber and complies with the relevant clauses of EN61326-3-1:2008, EN61000-6-2:2005 and EN55012:2007 for emissions and immunity. Niftylift offer a generator option on this machine, but cannot control the device that is connected to the system or the resulting variation in the amplitude of electrical noise produced when operating the generator. Niftylift therefore recommend that the generator is not used when the machine is located near any equipment that may be sensitive to electromagnetic disturbance.

Operating & Safety Instructions**2.2 ENVIRONMENTAL LIMITATIONS**

Unless specifically configured otherwise, the machine will have a short operational time in extreme temperatures such as freezers and cold storage, due to reduced battery performance. For electrical cables and components, the temperature must be within the range -5°C to 60°C.

The machine is limited in high temperatures because of the cooling requirement for engines and hydraulic oil. Coolant temperatures must be within the range -37°C to 110°C (at 50% mixture of water to anti-freeze). Oil temperature must not exceed -23°C to 93°C.

The recommended operational range for these machines is - 5°C to +30°C. Please contact Niftylift Ltd for special considerations if the machine is required to operate outside these temperatures.

Extended operation in dusty environments is not recommended; frequent cleaning will be necessary. All dust, dirt, salt encrustation, excess oil or grease should be removed. Deposits of paint or bitumen, particularly on legends or labels should be removed.

All standard Niftylift machines are rated for a wind speed of 12.5 m/s, which equates to 45kph / 28mph or force 6 on the Beaufort scale. No attempt should be made to operate a Niftylift in wind strengths above this limit and if the operator has any doubts over the wind speed they should cease operation immediately until it can be established that the wind speed has fallen to a safe level.



DO NOT USE THE NIFTYLIFT IN ELECTRICAL STORMS

2.3 NOISE AND VIBRATION

The airborne noise emission on the Height Rider range of machines does not exceed a sound power level of 105dB (A), measured within a hemisphere of 16m, under equivalent continuous A-weighted sound pressure test conditions. This was based on a Diesel powered machine, working on high throttle, and under load. All other models will exhibit significantly lower emissions than this figure, dependant on power option.

Sound pressure level at base controls does not exceed 76dBA, measured at 1.5m from floor and 1m from base control panel. The sound pressure level at cage controls does not exceed 78dBA, measured at 1.5m from cage floor.

In normal operation the vibration level to which the operator is subjected will not exceed a weighted root mean square acceleration value of 2.5 m/s².

2.4 TEST REPORT

All Niftylift machine models are subjected to a comprehensive 'type test' which examines the worst-case combination of safe working load (SWL), overload, windage, inertia and pull force to assess the various safe stability criteria. Self propelled machines are also subjected to kerb and braking tests at the SWL to satisfy additional dynamic stability requirements.

Each individual machine is then subjected to static overload tests on flat level ground with 150% of the SWL, exceeding the requirements of BS EN280:2013 for power operated MEWPs. Self propelled machines are also tested at the maximum working angle **plus** 0.5° with a test load of 125% of the SWL. Finally, on all machines, a functional test is performed with 110% of SWL.

All safety devices are checked for correct operation, operating speeds are checked against benchmark figures and the dynamic functions ensure that all acceleration and deceleration forces are within acceptable limits. All noted defects are rectified and recorded before the machine is permitted to enter into service.

3 Preparation and Inspection

3.1 UNPACKING

Since the manufacturer has no direct control over the shipping or carriage of any Niftylift it is the responsibility of the dealer and/or owner and/or lessee to ensure the Niftylift has not been damaged in transit and a Pre-operational Report has been carried out by a qualified engineer before the aerial platform is put into service.

- 1) Remove all ropes, straps, and or chains used to secure the aerial platform during transit.
- 2) Ensure any ramp, loading dock or forklift used is capable of supporting or lifting the aerial platform.
- 3) If the aerial platform is to be driven off, please ensure that the operator has read and fully understood this entire manual. Refer to the appropriate section for precise operating instructions.

****Carry out the Pre-operational Report (Refer to Section 6.3) before placing machine in service.**

3.2 PREPARATION FOR USE

Whilst every effort has been made at the Niftylift factory to ensure your machine arrives in a safe and operable condition it is necessary to carry out a systematic inspection prior to putting the aerial platform into service.



THIS IS NOT A REQUEST IT IS MANDATORY

To assist the user in this task you will find enclosed a Pre-operational Report, which must be filled out upon delivery/receipt of the machine.

Before the user carries out the Pre-operational Report he must have read and fully understood all the contents of the Operating, Safety and Maintenance Manual.



WARNING - DO NOT OPERATE A POTENTIALLY DEFECTIVE OR MALFUNCTIONING MACHINE. CORRECT AND REPAIR ANY DEFECTS BEFORE OPERATING YOUR NIFTYLIFT.



MACHINE STABILITY - The Hybrid machine requires battery mass for stabilisation. If the batteries or any other significant component have been removed, **the machine will be unstable**. Contact Niftylift, UK before removal or replacement of any significant component.

3.3 PRE-OPERATIONAL SAFETY CHECK SCHEDULES

Before use each day and at the beginning of each shift the aerial platform shall be given a visual inspection and functional test including, but not limited to, the following: It is recommended that these be performed at regular intervals as indicated on each checklist.

3.3.1 DAILY SAFETY CHECKS

- 1) Check that all labels (decals) are in place and legible
- 2) Visually inspect the machine for damaged or loose components.
- 3) Check that batteries are charged (Refer to Section 4.6 for further information).
- 4) Check the fuel level (if applicable).
- 5) Check that canopies/covers and guards are in place and secure.
- 6) Check that the boom rest switch is operable
- 7) Check that control levers are secure and operate freely.
- 8) Check that operating buttons and emergency stop buttons function correctly.
- 9) Check the operation of the manual hand pump.
- 10) Visually inspect all hydraulic hoses and fittings for damage or leaks.
- 11) Check that the platform pivot pins and their tag bolts are secure.
- 12) Check that the tilt alarm is functioning correctly (On a slope of 4° or more the alarm should sound and drive should be disabled).
- 13) Check the operation of SiOPS (Refer to Section 4.3.6).
- 14) Check the operation of the cage weigh system.

3.3.2 WEEKLY SAFETY CHECKS

- 1) Inspect tyres and wheels for damage and wear.
- 2) Check that the joystick manipulators are secure.
- 3) Check hydraulic oil level, ISO Grade 22 (Europe), Grade 32 (Rest of World).
- 4) Check engine coolant level. **Caution**, the cooling system is pressurised, so allow engine to cool sufficiently before removing filler cap.
- 5) Inspect the engine air filter and clean or replace if necessary.
- 6) Inspect hose track for damage or missing parts.

3.3.3 MONTHLY SAFETY CHECKS

- 1) Check the engine oil level. Check wheel nuts are secured (torque 166ft lbs / 225Nm).
- 2) Check that the slew worm is secured and correctly in mesh. Clean and re-grease.
- 3) Check the track rod linkages.
- 4) Inspect brakes for operation and wear.
- 5) Inspect the engine fuel tank for damage or leaks.
- 6) Check telescopic boom wear pads and nylon studs (if applicable).
- 7) Every **Six** months perform a **thorough examination** in accordance with the 'Lifting Operation and Lifting Equipment Regulations' (LOLER) 1998, Regulation (9)(3)(a).

3.3.4 ANNUAL SAFETY CHECKS

- 1) Check that all pivot pins and their tag bolts are secure.
- 2) Inspect for any cracks or badly rusted areas on booms and chassis.
- 3) Change the hydraulic oil filters.
- 4) Check the bushes in the front wheel hubs for wear.
- 5) Check that slew ring bolts are secure (torque 218ft lbs. 295Nm).

Toughcage

Niftylift **toughcage** is fully UV stabilised for outdoor use in the most demanding climates. However, the user and machine owner should consider the following;

- Discolouration of the material may occur; this is a natural aging process which does not significantly alter the material properties.
- Degredation to the floor may occur as a consequence of product use and effect of UV exposure. The **toughcage**'s multi-layer construction means degradation of the top surface may occur over time without compromising the structural strength of the internal and base layers.
- The rate at which the **toughcage** floor ages is dependent upon the machines application and its country of use (Typical levels of UV exposure). Refer to table below for aging rate applicable to your specific area.

UK, NETHERLANDS, GERMANY, POLAND, SCANDINAVIA, CANADA, RUSSIA	14 years
FRANCE, ITALY, USA (NORTH EAST STATES)	11 years
SPAIN, GREECE, TURKEY, CHINA, USA (MID WEST STATES), AUSTRALIA (TASMANIA)	9.5 years
MALAYSIA, INDONESIA	8 years

USA (SOUTH STATES), SOUTH AMERICA, AUSTRALIA (VICTORIA, NEW SOUTH WALES)	7.5 years
USA (WEST STATES), SOUTH AFRICA, INDIA, PAKISTAN, IRAN, AUSTRALIA (WESTERN, SOUTH, QUEENSLAND)	7 years
NORTH AFRICA, SAUDI, DUBAI, AUSTRALIA (NORTHERN TERRITORY)	6 years

Note: The date of manufacture of the **tough**cage floor is located on its underside.

Niftylift recommends that the user and machine owner **regularly** inspect the **tough**cage floor for damage. If any significant damage is found then the floor **must** be replaced. For further guidance please contact Niftylift Limited.

3.4 PLACARD, DECALS & INSTALLATION (UK SPEC)


ITEM	DESCRIPTION	NUMBER	QTY
1	Serial Plate	P15383	1
2	Clunk Click	P19961	1
3	IPAF 'Are you trained?'	P22055	2
4	Caution - 'SiOPS'	P22820	1
5	"If E-Stop Disabled	P14864	2
6	'Do not place objects on controls'	P21511	1
7	Danger Warning - Icons	P29379	1
8	Danger Warning - Text	P29380	1
9	Hydraulic levers – Base (on canopy)	P29752	1
10	Battery Drain	P19850	1
11	Daily Checks	P14908	1
12	Diesel	P14414	1
13	Emergency controls location	P21700	1
14	Operating Instructions	P14892	1
15	Chain Inspection	P16535	1
16	Hydraulic Levers – Base	P29667	1
17	Manual Descent	P29668	1
18	Hydraulic Oil	P14415	1
	Low Temperature Bio Oil	P23622	1
19	Pressurised tank	P16365	1
20	Oil Level Indicator	P14676	1
21	Battery disconnect	P29666	1
22	Do not jet wash	P29665	2
23	Charger Socket 240V	P26425	1
24	Charger Socket 110V	P26424	1
25	Isolator button	P26724	1
26	Point Load 40.6 kN	P20709	4
27	Lifting point	P14786	4
28	Tie Down Points	P14958	4
29	Gearbox Disengage	P18811	2
30	General crush hazard	P14782	9
31	No Step	P14785	2
32	Hot surfaces/Moving objects	P22314	1
33	Noise Warning 105dB	P29974	1
34	Level Sensor testing	P23801	1
35	Raise flyboom	P19442	1
36	Slew pin	P18517	1
37	Harness Point	P14883	2
38	Cage Gate Warning	P18335	1

***nifty* Height Rider/SP Series**
Operating & Safety Instructions

39	SWL 250kg		P28294	1
40	Footswitch		P14884	1
41	Cage Tie-down Warning		P21404	2
42	Logo	HR21	P16998	2
		SP64	P19070	2
43	4X4		P14697	2
44	"Niftylift.com"		P14389	1
45	Travel Direction		P29066	2
46	Hazard tape		N/A	N/A
47	Power to Cage Socket	240V	P26427	2
48	Power to Cage Socket	110V	P26426	2
49	Generator to cage (Option)		P28828	1
50	Compliance statement (USA)		P25250	1
51	Rotating machinery (USA)		P15010	2
52	Fuse box No.1		P29801	1
53	Fuse box No.2		P30819	1
54	Fuse box No.2		P33664	1
55	Fuse box No.3		P29921	1
56	Fuse box No.3		P33665	1
57	Cage controls		P29435	1
60	Base controls		P27596	1

nifty Height Rider/SP Series

Operating & Safety Instructions



3.5 TORQUE REQUIREMENTS

Bolt quality/size		Tightening torque in Nm (ft-lbs)				
		Plated			Unplated	
Grade		8.8	10.9	12.9	8.8	10.9 12.9
M6		7 (5)	10 (8)	12 (9)	8 (6)	11 (8) 13 (10)
M8		17 (13)	25 (18)	29 (22)	19 (14)	27 (20) 32 (23)
M10		34 (25)	49 (36)	58 (43)	37 (27)	54 (40) 63 (46)
M12		58 (43)	85 (63)	99 (73)	63 (47)	93 (69) 108 (80)
M14		93 (68)	135 (100)	158 (117)	101 (74)	148 (109) 172 (127)
M16		143 (106)	209 (154)	245 (180)	156 (115)	228 (168) 267 (197)
M20		288 (212)	408 (301)	477 (352)	304 (224)	445 (328) 521 (384)
M24		491 (362)	698 (515)	816 (602)	519 (383)	760 (561) 889 (656)
WHEEL NUTS					225 Nm (166ft lbs)	
WHEEL GEARBOX NUTS					215 Nm (158ft lbs)	
SLEW RING BOLTS					295 Nm (218ft lbs)	

This torque chart is based on the following assumptions:

- 1) Bolts to ISO 898-1 "Mechanical properties of fasteners made of carbon steel and alloy steel"
- 2) For "unplated" bolts, all grades:
 - Hex head bolts
 - Black oxide steel bolt with a rolled & oiled thread, no finish on steel nut
 - Prevailing torque includes Nylock (minimum prevailing torque figure assumed)
 - Medium Clearance holes to ISO 273
 - Bolt tightening condition = Yield factor of 75%
- 3) For "plated" bolts, all grades:
 - Hex head bolts
 - Zinc plated oiled (rolled or cut) steel external thread with no finish on steel internal thread
 - Prevailing torque includes Nylock (minimum prevailing torque figure assumed)
 - Medium Clearance holes to ISO 273
 - Bolt tightening condition = Yield factor of 75%

Figures quoted in **Nm** have been calculated in Nm and then rounded to the nearest whole number. Figures quoted in **lb-ft** have been calculated in Nm, converted using a factor of 0.737561 and then rounded.

4 Operation

4.1 CONTROL CIRCUIT COMPONENTS

4.1.1 GROUND CONTROLS

PROGRAMMABLE LOGIC CONTROLLER (PLC): - Situated under the ground controls canopy, behind the Ground Controls Station is the PLC. Its purpose is to receive signals from **all** areas of the control, to process the instructions and machine status, and to safely operate the relevant machine functions.

TILT SENSOR: - Installed on the superstructure under the links lift cylinder, the tilt sensor is a solid-state sensor, which monitors the inclination of the machine chassis. When the platform is in use, (i.e. Booms are raised), if the inclination exceeds the pre-set limit, it will disable all drive functions and sound the alarm. In order to recover the machine, boom operation is unaffected, allowing the operator to restore drive by lowering the booms into the stowed position. It is then possible to drive back onto level ground, fully restoring machine operation.

MULTI-TONE SOUNDER & BEACON

The Niftylift will warn personnel that the machine is about to move when the green power button or footswitch is pressed. The machine's default setting is to sound a beeper at the base control location and flash a beacon mounted on the top of the engine canopy. However, the machine can be configured to select either the sounder or the beacon if site conditions require the machine to behave differently. (e.g. Beacon only, when used at night in a residential area). It is mandatory that one alert device is functioning, and it is not possible to turn off or permitted to disable both the beacon and sounder.

If a safety-critical situation occurs, the sounder will emit a "ricochet" sound to alert the user and nearby personnel. This warning occurs even if the motion sounder setting has been disabled.

Cage Weigh: - If the electronic load cell detects an overload condition, the machine will sound continuously in conjunction with the cage overload warning light.

Battery management: - when a low battery state is reached, the "pulsing" of the D.C. motors is mimicked by the sounder reinforcing the message to the operator to charge the machine. Note; if the sounder activates whilst using electric power only, it is advisable to start the engine enabling the operator continued use of the machine, whilst recharging the batteries.

HORN: - Located on the side of the ground control box is a horn, which is used as a manual alert, by pushing the "Horn" button on the Platform Control Panel.

BOOM SWITCH: - Mounted on the links knuckle and operated by the raising of link booms or upper boom, this switch controls both the operation of the Tilt Sensor, and the speed control function. With the booms in the stowed position, the Tilt Sensor is by-passed, allowing the machine to negotiate slopes in excess of the permissible elevated working angle, without isolating the drive function. At the same time, High Speed drive (Depicted by a Hare Icon) is possible. When the booms are raised the Tilt Sensor is activated and only Slow Speed drive is permitted. These control functions are of primary importance to safety of the machine and operator; **under no circumstances should this control function be isolated or by-passed.**

TELESCOPIC BOOM SWITCH: - Mounted inside the Telescopic Boom, this switch controls the operation of the Tilt Sensor and Speed Control function as described in the previous paragraph.

4.1.2 PLATFORM

CAGE DISPLAY UNIT: - Mounted in the Platform Control Station, this screen receives signals from the PLC to provide a warning indication to the operator for a range of functions. Refer to Section 4.3.2 for further details.

LOAD SENSING CONSOLE (SiOPS™): - This machine incorporates a load sensing console that senses if the operator has been pushed or has fallen against the console. If the load applied to the front of the console is greater than the pre-determined amount, the footswitch will be disabled to increase operator safety and reduce the possibility of sustained involuntary operation of the cage controls. For further information refer to Section 4.3.6.

4.1.3 CHASSIS

MOTION CONTROL VALVE: - This valve comprises several individual components all directly involved in the hydraulic supply to the wheel drive motors. Amongst these are the drive control valves which allow the operator to propel the machine forward or backward by using the Joystick (See Section 4.3.1).

In addition the Brake Release Valve (BRV) is also incorporated into this valve block. It is a solenoid operated valve, which controls the brake function on the machine. This valve must be energised to allow the machine to move. If no voltage is present, the wheel motors will not be able to develop drive torque, whilst at the same time, the parking brakes will remain engaged. The BRV will only operate when a green power button is being used (or the Platform Foot-switch is depressed) in Drive mode. If the tilt sensor detects an excessive inclination whilst the booms are raised it is the BRV which is de-energised to isolate the machine.

4.1.4 FUSES

Power Tray (Hybrid)

- 10A** (58VDC) Fuse inside Module box 2
- 20A** (32VDC) Fuse (Module box 3)
- 50A** (32VDC) Fuse (Module box 3)

Power Tray (Diesel)

- 40A** (32VDC) Fuse (Module box 3)
- 20A** (58VDC) Fuse (Module box 3)

Ground Control Station

- (Hyb) **125A** Fuse on Ground Control Tray
- (D) **325A** Fuse on Ground Control Tray
- 225A** Fuse on Ground Control Tray
(If auxiliary descent pump is fitted)

Module Box 1

(Refer to HR21 MK2 Service Manual for fuse layout diagram)

Chassis


- 325A** Fuse inside base (Hybrid)

Platform Control Station

- 1 x 5A** blade fuse behind Control Panel
- 2 x 3A** blade fuses behind Control Panel

4.2 GROUND CONTROL OPERATION

4.2.1 GROUND CONTROL FUNCTIONS




1 Emergency Stop	Push to Stop Operation	Twist to Enable Operation
2 Green Power Button	Push and hold for Power	Release to Cease operation
3 Base/Platform Selector	Clockwise for Platform, Centre for Base, 0 for all power off	
4 Engine Glow & Start/Stop	Anti-clockwise for Glow , Clockwise to Start/Stop engine	
5 Status Lamp	Red flashing: Indicates safety critical problem. Refer to digital gauge immediately	
6 Display Screen	See Section 4.3.2	

nifty Height Rider/SP Series

Operating & Safety Instructions

Base Levers



1 Operates Platform Levelling	Forward for Up	Backward for Down
* 2 Operates the Flyboom	Up for Up	Down for Down
* 3 Operates Telescoping	Up for Out	Down for In
* 4 Operates the Link Booms	Up for Up	Down for Down
* 5 Operates the Upper Boom	Up for Up	Down for Down
* 6 Operates Slew/Swing	Up for Right	Down for Left
7 Operates Front Wheel Steer	Forward for Right	Backward for Left

*** More than one function can be operated at the same time**

4.2.2 OPERATION

ALWAYS ALLOW THE ENGINE TO WARM UP BEFORE OPERATING



ALL MODELS

- 1) Ensure all red emergency stops are out and engine battery disconnect knob is turned fully clockwise.
- 2) Turn key switch at ground control station to **Ground** (Single turn clockwise).
- 3) For **Battery** powered operation, go to step 7).
- 4) For **Diesel** powered operation, go to step 5).

DIESEL ENGINE

Note: On the HR21D (Diesel only) the engine will not start if the footswitch or Green button are pressed, or the machine is switched to generator.

- 5) **COLD ENGINE:** - turn the **Diesel Glow/Start** selector to the **Glow** position (anti-clockwise). This engages the glow plug pre-heat system. Hold for 5-10 seconds then turn the key to the **Start** position (fully clockwise) and the engine will fire.
- 6) **WARM ENGINE:** - turn the **Diesel Glow/Start** selector to the **Start** position (clockwise) and the engine will fire.

Note: Unless the diesel engine is running, the HR21 Hybrid will automatically default to the electrical power source (battery).

Operating & Safety Instructions

ALL MODELS

- 1) Push and hold green power button on the base control panel.
- 2) Select a function and operate the appropriate control lever(s) in full accordance with the manufacturers operating and safety manual. (Refer to Section 4.2.1)
- 3) To return control to the platform, turn base control key-switch to the **Platform** position (fully clockwise).
- 4) When not in use return machine to stowed position. **Note:** Fully lower the Link booms first (Lever 4) followed by the Upper boom (Lever 5) for smooth operation. Turn the base control key-switch anti-clockwise to the **OFF** position, remove key and chock wheels.

EMERGENCY PROCEDURES

- 1) **Push in** red emergency stop to shut down **all** machine movement.
- 2) **Release** both emergency stops to restore normal controls.

In the event that the controls fail, the cage overload is activated due to contact with a fixed object or a cage operator is incapacitated, the booms can be operated from the base location as described below:

If normal controls are available (fastest recovery time):


- 1) Turn key switch to ground, press the green button and operate the desired function lever(s).

If normal controls are **not** available:

- 2) Locate the **manual hand pump** under the control side canopy.
- 3) Attach supplied handle to the hand pump.
- 4) Move and hold the desired boom function lever in the required direction.
- 5) Pump the hand pump to activate the selected function.
- 6) Release the lever and stop pumping to halt machine movement.
- 7) If recovering the machine because cage overload has deactivated the machine due to contact with a fixed object, then moving the machine slightly using steps 1-5 should be sufficient to re-enable normal operation. The cage overload alarm and visual warning will cease once normal controls are available.
- 8) If normal controls are still not available, continue pumping to lower the machine manually.

4.3 PLATFORM CONTROL OPERATION

4.3.1 PLATFORM CONTROL FUNCTIONS



The platform controls are designed to prevent inadvertent operation of the machine and the user must be familiar with the following safety features.

- 1) **Footswitch timeout** – If the footswitch or green button is pressed, but no function is activated within 15 seconds, the machine will not function until the footswitch or green button is **released and re-pressed**.
- 2) **Controls neutral check** – If a boom control paddle or the drive joystick is moved from its neutral position **before** the green button or footswitch is pressed, that function will not be available until the control is returned to its neutral position and a deliberate action is taken to move the function **after** the green button or footswitch is pressed.
- 3) **Joystick Trigger timeout warning** – If the joystick trigger is pressed, but the machine is not driven within 30 seconds, then the machine will warn that the trigger has been held.

1 Engine Glow/Start/Stop	Anti-clockwise hold for Glow		Clockwise to Start/Stop engine
2 Speed Selector <i>Booms Drive</i>	Left - Speed I Tortoise	Centre - Speed II Off-road	Right - Speed III Hare
3 Platform rotation	RH arrow for Anti-clockwise		LH arrow for Clockwise
4 Horn	Press & hold to Sound		
5 Safety Warning Lamp	Indicates Safety Critical Problem (Refer to Digital Gauge immediately)		
6 Display screen	See Section 4.3.2		
7 Auxiliary powered descent	Push and hold to enable boom functions in the event of normal operation loss. (i.e. fuel tank empty)		
8 Emergency Stop	Push to Stop Operation		Turn clockwise to Release


Operating & Safety Instructions

9 Green Power Button	Push and hold to activate machine	
10 Joystick	Grip the joystick and hold the trigger switch at the front. Machine movement is achieved by slowly moving the joystick away from the neutral position in the required direction. Steer by using the thumb rocker switch located on top of the joystick.	
* 11 Operates Link Booms	Up for Up	Down for Down
* 12 Operates Upper Boom	Up for Up	Down for Down
* 13 Operates Swing	Left for Left	Right for Right
* 14 Operates Telescoping	Up for Tele-In	Down for Tele-Out
* 15 Operates the Flyboom	Up for Up	Down for Down
16 Generator switch (Option)	Turn Clockwise to activate generator	

* **More than one function can be operated at the same time**

4.3.2 DISPLAY SCREEN

Situated on the Ground and Cage Control Panels, this gauge provides operational and/or a warning indication for a range of functions. For further information refer to Section 4.3.3 'Information Icons' on Page 29 or Section 4.3.4 'Menu Screens' on page 31. During machine operation the gauge displays current fuel and battery level (Hybrid), cage load status and current boom/drive speed setting.



If the control system detects a malfunction on the machine one or more of the icons in the **status bar** will illuminate. Please refer to Section 4.3.3 for further info.

4.3.3 INFORMATION ICONS

Safety Critical (Main screen)



MAX tilt angle exceeded:- The alarm sounds, the display shows this image and drive is disabled. Lower booms down into the stowed position and drive onto level ground to fully restore machine operation.



Safe Working Load (SWL) exceeded:- The alarm sounds and the display will show this image. The Maximum SWL (250kg/550lbs) has been exceeded. Immediately remove any unnecessary items from the platform **in a safe manner** to restore machine functions.

Alternatively, the platform may have come into contact with a fixed object, see Section 4.3.5 for recovery procedure.

Note: If a **Safety Critical** condition has been detected, the safety warning lamp on the Platform Control Panel and Base Control Panel will also illuminate.

Advisory (Main screen)



Release E-Stop:- Machine will not operate as one or both of the Emergency Stop buttons are pressed. Twist and release to restore normal controls.



Footswitch Timeout:- Machine will not operate. Release and re-press footswitch or green button to restore normal controls (Refer to Section 4.3.1).



Controls Neutral:- Boom control paddle or drive joystick has moved from the neutral position **before** the green button or footswitch was pressed. Return to neutral position and move **after** green button or footswitch has been pressed (Refer to Section 4.3.1).



Joystick Timeout:- Machine drive will not operate. Release and re-press trigger to restore normal controls (Refer to Section 4.3.1).



Fuel Level Low: Flashing fuel pump icon indicates fuel tank is <10% full. Amber level indicates fuel tank is <30% full.

Operating & Safety Instructions


Advisory (Mode of operation)



Boom Function Speed: Determined by the Speed Selector switch on the Cage Control Panel (Refer to Page 27).



Drive Speed: Determined by the Speed Selector switch on the Platform Control Panel (Refer to Page 27). Digital display reverts to these icons once the joystick trigger is activated.



Ground Controls: To enable **platform** controls, selector switch located on ground controls must be turned clockwise (Refer to Section 4.2.1, Item 3).



Generator: Generator is switched on and in use.



Auxiliary: Auxiliary power is in use.

Status Bar

If icons on the status bar are 'greyed out' this indicates normal operation.



Engine

Amber: Low oil pressure or high water temperature.

Red: Engine malfunction.
(May illuminate in conjunction with the General Error icon)

Press **Button 1** for further information.



Electric Motor (Hybrid)

Red: Error detected.

Press **Button 1** for further information.



Tilt Warning

Red: Max tilt angle exceeded.
(Refer to 'Safety Critical (Main screen)' section on page 29).



Cage Overload Warning

Red: SWL exceeded.
(Refer to 'Safety Critical (Main screen)' section on page 29).



Cage Overload Override Evidence

Amber: Cage overload has been overridden.
This will remain until reset.

Red: Malfunction.



In order to reset overload override evidence, press **Button 3** and follow on-screen instructions.



General Error


Amber: General error.

Red: Critical error.

Press **Button 1** for further information.



4.3.4 MENU SCREENS




DIAGNOSTICS



To access this screen, press button **1**.

This displays options to access Error Codes, Software Version, Joystick Position, Paddle Position, Safety Switches and Engine Status information.

Scroll up or down to the information required using the arrow keys and press the right arrow key or **ok** to open the screen. Press Left arrow key or button **1** to return to previous screen.



Error Codes


If the control system detects a malfunction on the machine, an error code will be displayed. For further information refer to **Appendix A**, or the HR21 MK2 Service Manual.

Operating & Safety Instructions




Software Version

Displays the version of software installed in the programmable devices on the machine.




Joystick Position

The screen displays signal function whilst operating the Joystick. The coloured squares on the screen should move in relation to the movement of the joystick.




Paddle position

The screen displays signal function whilst operating any cage control paddle. The coloured squares on the screen should move in the same direction as the paddle.



Safety Switches


A **GREY** square indicates that particular machine function is not fully stowed. If the function is in the stowed position the square will be displayed as **GREEN**.



Engine Status

If any square is red, the engine should be switched off **immediately**. The engine coolant or oil level should be checked once the engine has cooled sufficiently. Refer to Niftylift Service Manual for further information.

This screen can be accessed at any time to check Engine RPM, oil pressure and water temperature status.




MACHINE HOURS



To access this screen, press button **2**.

Total active, Booms active, Drive active and Engine Running hours are displayed.



SENSOR RESETS





To access this screen, press button **3**.

To reset either the Cage overload override evidence or the Chassis zero, contact Niftylift and quote the reference number displayed on the screen.



Niftylift will supply a code which must be entered by using the arrow keys.




SETTINGS



To access this screen, press button **4**.

Beacon/Sounder, Select Language and Cage Rotate (Ground Controls ONLY) options are displayed.

Scroll up or down to the information required using the arrow keys and press the right arrow key or **ok** to open the screen. Press Left arrow key or button **4** to return to previous screen.



Beacon/Sounder

This allows the operator to select between the beacon or sounder for a motion alert.


Note: Either the Beacon or Sounder **MUST** be enabled; the system will automatically select one if the operator attempts to deselect both.

Operating & Safety Instructions



Select Language

This allows the operator to choose a language for the menu screens.



Cage Rotate (Ground Controls Only)

This allows the operator to rotate the cage from the Ground Controls.

Push and hold green power button on the ground control panel. Press either the left or right arrow on the navigation button (Refer to Section 4.3.2) as required. The on screen direction arrow will revert to orange.

4.3.5 OPERATION



NEVER START THE NIFTYLIFT IF YOU SMELL PETROL (GASOLINE), LIQUID PROPANE OR DIESEL. THESE FUELS ARE FLAMMABLE.

BEFORE OPERATING THE NIFTYLIFT ENSURE THAT EACH OPERATOR HAS READ AND FULLY UNDERSTOOD THE OPERATING MANUAL. FAILURE TO DO SO MAY RESULT IN DEATH OR SERIOUS INJURY.

ALL MODELS

- 1) Ensure all red emergency stops are out and engine battery disconnect knob is turned fully clockwise.
- 2) Turn key switch at ground control station to **Platform** (fully clockwise).
- 3) For **Battery** powered operation, go to step 7).
- 4) For **Diesel** powered operation, go to step 5).

DIESEL ENGINE

Note: On the HR21D (Diesel only) the engine will not start if the footswitch or Green button are pressed.

- 5) **COLD ENGINE:** - turn the **Diesel Glow/Start** selector to the **Glow** position (anti-clockwise). This engages the glow plug pre-heat system. Hold for 5-10 seconds then turn the key to the **Start** position (fully clockwise) and the engine will fire.
- 6) **WARM ENGINE:** - turn the **Diesel Glow/Start** selector to the **Start** position (clockwise) and the engine will fire.

Note: Unless the diesel engine is running, the HR21 Hybrid will automatically default to the electrical power source (battery).

ALL MODELS

- 7) Set the **speed selector** control as required. Speed **I** gives **minimum** function control speed and Speed **III** allows **maximum** function control speed.
- 8) Depress the footswitch or push and hold green power button on the platform control panel.
- 9) Select one or more functions and operate the appropriate proportional paddles (levers) in full accordance with manufacturers operating and safety manual.
- 10) To return control to the base, turn the base control key-switch to the **Base** position (centre).
- 11) When not in use return booms to the stowed position. **Note:** Fully lower the Link booms first (Lever 4) followed by the Upper boom (Lever 5) for smooth operation. Turn key switch on the ground control station to the fully anti-clockwise **OFF** position, remove key and chock wheels.



ALWAYS ENSURE THE AERIAL PLATFORM IS ON A FIRM LEVEL SURFACE AND THE AREA IS FREE OF ANY OVERHEAD OBSTRUCTIONS.

ENGAGING THE RED EMERGENCY STOP BUTTON WILL SHUT DOWN THE ENGINE AND THE ELECTRIC CIRCUIT, PREVENTING OPERATION OF ANY FUNCTION.

Operating & Safety Instructions

EMERGENCY PROCEDURES

- 1) Push in red emergency stop to shut down **all** machine movement.
- 2) **Release** both emergency stops to restore normal controls.

In the event that the controls fail or the cage overload is activated as described in Section 5.3, the booms can be operated from the cage location as described below:

- 1) Press **white override button** situated on the cage console. (Refer to Section 4.3.1)
If engine is running, it will stop. Override mode is for booms only and will not operate drive.
- 2) Activate a **single** desired function paddle.
(Note: Multiple boom function is not available in override mode).
- 3) If the cage has contacted a fixed object and cage overload has disabled the machine, move machine slightly using steps 1-2. The overload alarm and visual warning will cease and normal controls are available.
- 4) Restart engine with selector switch.
- 5) Use normal controls if available for the fastest recovery time. Press the green button or footswitch and operate the desired function lever(s).
- 6) If normal controls are not available, continue using the override button to lower the machine using auxiliary power.

Note: The override mode is for **booms only** and will not operate the drive function. If the engine is running, it will stop once the override button is pressed.

4.3.6 SiOPS™ - LOAD SENSING CONSOLE



WHEN OPERATING THIS MACHINE THE USER MUST BE AWARE OF ANY OVERHEAD OBSTRUCTIONS.

This machine incorporates a load sensing cage console that senses if the operator has been pushed or has fallen against the console. If the load applied to the front of the console is greater than the pre-determined amount, the footswitch will be disabled to increase operator safety and reduce the possibility of sustained involuntary operation of the cage controls.

Note: The green button will illuminate once the footswitch has been disabled, but continues to be available for use at all times. This allows the operator to use the cage control functions and manoeuvre the machine to a safe position. If cage overload has also activated, the procedure described in Section 4.3.4, 'Emergency Procedures' (above) should be followed first.

To reset the footswitch and normal controls:

- 1) Release the load from the front of the console.
- 2) Ensure cage controls are in the neutral position and clear of objects.
- 3) Raise foot clear of footswitch then lower foot onto footswitch to reactivate.

Note: If SiOPS™ has been activated and the footswitch is not reset within **15 seconds**, then the blue warning beacon will flash (located on underside of the cage) and a warning announcement will sound until the footswitch is reset as described previously.

4.4 DRIVING CONTROLS



DO NOT OPERATE THE NIFTYLIFT WHILST ELEVATED UNLESS ON A FIRM, LEVEL SURFACE FREE FROM ANY POSSIBLE OBSTRUCTIONS OR HAZARDS BOTH AT GROUND LEVEL AND OVERHEAD.

- 1) Check proposed route for possible hazards, obstructions and personnel.
- 2) Depress footswitch located on platform floor.
- 3) Set the **speed selector** switch on the platform control station as required.

Tortoise (Low Speed) - gives low speed and low engine revs.

Off-road (High Gradeability) - gives low speed and high engine revs.

Hare (High Speed) - gives high speed and high engine revs.

Note: High Drive Speed (Hare) is only available when the booms are in the stowed position. **The HR21 will default to Elevated Drive speed whenever the booms are elevated.** At this point **Off-road** or **Tortoise** can be selected to determine the most appropriate mode for the current terrain.

If the machine is driven using High Drive Speed (Hare) on slopes exceeding 10° it automatically reverts to **Off-road** speed (High Gradeability). To return the machine to High Drive Speed, drive on to level ground (<10°) then release and reactivate the joystick or footswitch.

- 4) Select drive joystick from the platform control panel.

Push forward for **FORWARD DRIVE**

Pull backwards for **REVERSE DRIVE**

Steering is controlled by the rocker-switch button on the top of the joystick

Left for **STEER LEFT**

Right for **STEER RIGHT**

The driving horn is activated by a button on the platform controls (Refer to Section 4.3.1).

All control levers give a fully proportional response therefore the more the lever is moved away from the centre **off** position the faster the function will become.

When driving with the booms fully stowed, the Tilt Sensor is bypassed to allow the Niftylift to be driven in areas where the slope exceeds the allowable inclination limit. In normal operation the drive is therefore unaffected when driven onto a slope in excess of this limit, until the booms are raised, whereupon the drive is disabled and the tilt alarm sounds continuously.



ALL NIFTYLIFTS ARE FITTED WITH A TILT ALARM - PRE-SET IN THE FACTORY. ONCE ENERGISED, THE NIFTYLIFT WILL LOSE ALL POWER TO DRIVE FUNCTIONS AND A LOUD AUDIBLE ALARM WILL BE ACTIVATED.

TO DE-ACTIVATE, LOWER THE BOOMS FULLY TO THEIR STOWED POSITION AND RE-POSITION BASE ON FIRM, LEVEL GROUND.

IF ALARM SOUNDS - DESCEND IMMEDIATELY AND RE-LEVEL MACHINE BASE.

Operating & Safety Instructions

4.5 CAGE WEIGH SYSTEM

4.5.1 LOAD CELL VERSION

The Niftylift HR21 is fitted with an electronic load cell. This load cell is a moment-independent design. This means that independent of the load position inside the machine cage, the actual load is measured and if pre-calibrated limit values are exceeded, warnings will be activated. If load exceeds the safe working limit (SWL) of the machine, the machine will be disabled until the load is reduced to below 95% of the safe working limit. The design of the unit meets the requirements of both BS EN 280 and ISO 13849 with a safety integrity level of "Category 3 PL d. (Refer to Appendix A)

The current load in the cage is displayed on the digital display unit as a percentage of SWL. Please refer to Section 4.3.2.

4.5.2 CALIBRATION, INSPECTION AND MAINTENANCE

Calibration, maintenance and repair of the Niftylift HR21 cage load cell requires specialist knowledge and equipment. **For this reason, no part of the Niftylift HR21 cage-weigh system can be adjusted, repaired or inspected by the operator.**

All enquiries relating to calibration, inspection or maintenance should be directed to Niftylift or one of their approved dealers. Contact details are listed in Section 1.3.

4.6 BATTERIES AND CHARGING (Hybrid)



BATTERIES MUST BE RECHARGED IN A WELL-VENTILATED AREA FREE OF FLAME, SPARKS OR OTHER HAZARDS THAT MAY CAUSE EXPLOSION. HIGHLY EXPLOSIVE HYDROGEN GAS IS PRODUCED DURING THE CHARGING PROCESS.

- 1) Recharge batteries at the end of every working day or shift.
(**Note:** To recharge batteries fully from 20% takes approx. 12 Hours, this consists of 8 hours bulk charging plus 4 hours equalisation. The recharging time can be reduced to approx 4- 6 hours by running the engine whilst charging).
- 2) Plug charger into suitable power supply, either 240 volts or 110 volts AC (see **Charging Limitations**). (Note: If using 240V, use of a suitably rated Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD) at the point of supply is highly recommended.)
- 3) Take note of the indicators provided:
Pulsing Green 50% LED - Batteries are charging and between 0 & 50% capacity.
Constant Green 50% LED and pulsing Green 75% LED - Batteries are charging and between 50% & 75% capacity.
Constant Green 50% & 75% LED's, plus pulsing Green 100% LED - Batteries are charging and between 75% & 100% capacity.
Constant Green 50%, 75% & 100% LED's – batteries are fully charged.
Red Gel lamp – Only applicable to sealed type batteries.
- 4) The charger will automatically switch off once the batteries are fully charged. It is recommended to reconnect the charger to a suitable power supply when the machine is not in use to maintain good battery condition. Charger will monitor and maintain correct battery charge level.



UNDER NO CIRCUMSTANCES SHOULD A MACHINE BE LEFT FULLY DISCHARGED AS SEVERE BATTERY DAMAGE CAN OCCUR IN A RELATIVELY SHORT TIME.

- 5) The machine boom functions can be used whilst on charge. **Do not drive** machine to avoid damage to cables etc. To disconnect charger, firstly switch off the power supply. Ensure LEDs are **off** before disconnecting the charger from the power supply.

Notes:

- 1) If the charger is reconnected to the power supply shortly after it has gone through its full charging cycle, the charger will show a Green 50% light, immediately followed by the Green 75% lamp. The charger would then go through its complete cycle again at an accelerated rate, depending on the time difference between connection, reconnection and level of battery charge.
- 2) Some machines are fitted with a Battery Management System, which permanently monitors the condition of the batteries. When the batteries become discharged to 20% of their capacity the management system will begin to "shut down" the hydraulic power packs. This causes the drive/boom operating system to alternately stop and start, signalling to the operator that re-charging is necessary. However, there is sufficient power remaining to enable the operator to drive slowly to the nearest charging point.

Operating & Safety Instructions

- 3) During normal machine usage with the engine running, the batteries are on continuous recharge, except when the control system decides that additional electric power is required in order to maintain drive/function speed.

Should the operator ignore the onset of the battery discharge warning the "shut down" of the motors will continue, until the machine is rendered in-operative. **Immediate charging will then be required.**

CHARGING LIMITATIONS

The capacity of the 110V supply must be capable of 3.5kVA (32A current); hence a small hand-tool transformer must **not** be used with the battery charger.

Note; charger output will fall if air temperature is below 0°C or above 50°C.

Fault Conditions

If a fault occurs, count number of flashes between pauses and refer to table:

	LED status	Description
Fault	3 green LEDs blink once simultaneously	Output is open or short, output voltage is over limit or output terminals are reversed
	3 green LEDs blink twice simultaneously	Input voltage not within range
	3 green LEDs blink three times simultaneously	Internal temperature charger limit exceeded
	3 green LEDs blink four times simultaneously	Output current limit exceeded
Warning	Green 100% LED blinks continuously	18 hour timer has deactivated the charger due to battery problem. To reset, turn charger off, wait 30 seconds before switching on.

Note; If a fault occurs, the charger emits an audible warning. In addition, if the fault is rectified the charger will restart automatically.

Attention should also be given to the use of extension cables as power leads. Excessive cable lengths from the supply point to the battery charger will result in significant voltage drop, leading to a reduction in the chargers efficiency. In addition, inadequate sized cable cores will have a limiting effect on its current carrying capacity, which will again lead to a reduction in the chargers efficiency. Both of these can result in over-heating of the cable with an increased risk of fire, short circuits or damage to the components themselves.

The charger requires a minimum battery voltage of 1.5 volts per battery (overall for two batteries 3 volts, for 4 batteries 6 volts for 8 batteries 12 volts and 18V for 72V). If the voltage is below these values then the charger will not function (Charger will not detect batteries to begin charge.) If the batteries have fallen to such a poor state they will have to be removed from the machine and charged individually with an independent charger until the optimum voltage has been reached. This is best performed at very low currents to 'recover' the batteries if sulphation has already started i.e. a 'trickle' charger. This can take several hours, possibly days. Careful monitoring of the rise of battery voltage will indicate when recovery has been achieved.

BATTERY CONTROLLER

This machine is fitted with a Battery Management System that monitors battery condition. A main component of this is the Battery Controller Unit. If for any reason the battery controller circuit has been disconnected, please ensure that the batteries are **fully recharged** before using the machine as this enables the Battery Controller Unit to reset automatically.

*Note; this requirement does not apply if the battery isolating handle (Anderson connector) **ONLY** has been disconnected.*

The Battery Controller Unit has been calibrated to function correctly with Niftylift factory fitted batteries. If for any reason you suspect **any** of the batteries have been replaced with a non-factory fitted unit then please contact the Niftylift Service Department on (44) 01908 857899, Fax: 01908 227460. As machine performance will be severely affected.

TOPPING UP

The batteries installed on this machine are **Maintenance Free**, therefore **DO NOT REFILL** with de-ionised water. Irreparable damage will occur.

4.7 TRANSPORTING, TOWING, CRANEAGE, STORAGE AND SETTING TO WORK

4.7.1 TRANSPORTING

If a work platform is to be moved over a longer distance, whether the machine is trailer mounted, vehicle mounted, self propelled or tracked, the following procedure should be read before restraints are attached to the machine. Cross loading is most frequently the cause of problems, as the method of loading is no longer in sight of our own personnel. The recommendations made herein should be passed on to subsequent carriers, such that the entire journey is carried out without incident.


- Always ensure the truck or trailer you are loading or towing the Niftylift with can carry it legally.
- If loading by crane the use of shackles and an adequately rated spreader beam, with four leg slings, is **MANDATORY**.
- When loading or un-loading from the side of the vehicle, the use of the forklift pockets to retain one of the forks is recommended. (If fitted). Spread the forks to their widest capacity, with due regard to the components fitted to the machine. Never forklift or crane an entire machine under the booms, always lift beneath the spine or under the ends of the axle mountings in the case of a self-propelled unit. Ensure forklift is adequately rated for the load to be carried.
- Once positioned on the transport carrier ratchet straps should be used to secure the machine. The machine should be positioned to allow easy access around the machine in transit, and to ensure that 'creepage' during transport does not permit the machine to come into contact with other goods being shipped, or the container itself. Some movement of the machine structure might occur during transit, which could lead to fretting or other damage.
- If the machine is equipped with a transit device such as a boom clamp etc, this should be securely applied.
- Strap booms carefully to constrain them from sideways movement. When using straps or chains, adequate packing should be applied to stop any damage to the structure and paintwork. Due regard of the movement of the straps or chains must be taken into account.
- Where a machine has designated points for strapping, lifting or forking, these can be used for tie-down duty. When they are absent, the major structure of the platform can be used, giving due consideration to the design and function of the area chosen. Where possible, use the spine of the machine or axle mounts over which to apply the holding down forces. Using a single plate, such as an outrigger or stabiliser support plate might be unsuitable. If the component was clearly not designed to accommodate a side load, one should not be applied.
- Under no circumstances should straps or chains be applied over booms or through the cage support structure or the cage itself. The relative strength of the carrying structure is not conducive to the massive forces capable of being applied through ratchet chains or slings. Severe damage to the steelwork can be caused, as well as deformation to sensitive mechanisms such as cage weigh assemblies, which would render them useless. Such catastrophic damage to say, an electronic load cell would require the component to be replaced before the machine would function.

4.7.2 TOWING

If the Niftylift needs to be towed in case of an emergency, it will be necessary to **chock the wheels** before starting any of the following actions.

IDENTIFYING GEARBOX TYPE


In order to safely tow the HR21, the drive mechanism will need to be bypassed. Identify the type of gearbox fitted to the machine then refer to the relevant procedure for disengagement of the gearboxes.



GEARBOX DISENGAGEMENT (TYPE 1)

The drive gearboxes located on the front and rear wheel hubs must be disengaged as follows;


- 1) To disengage the gearbox, remove both screws from the cover plate, turn it upside down (as per the diagram below), and re-tighten the M5 screws to a torque of 5 Nm (3.7lbf).
- 2) Before attempting to re-engage the gearbox, ensure that the machine is jacked up so the relevant wheel is clear of the ground in order to prevent damage. **Note; Damage caused by failure to comply with this notice will not be covered by the manufacturer's warranty.**



GEARBOX DISENGAGEMENT (TYPE 2)

The drive gearboxes located on the front and rear wheel hubs must be disengaged as follows;

- 1) Remove both retaining bolts that secure the cover disc to the centre of the wheel hub.
- 2) Partially screw one of the retaining bolts into the end of the central disengage pin and pull the pin out fully, ensuring the recess on the pin is visible.
- 3) Place the cover disc over the pin, ensuring the retaining disc is engaged in the pin recess and secure in place using the remaining retaining bolt.
- 4) To re-engage the gearbox, complete the above instructions in reverse order, ensuring gearbox drive is free to engage before pushing the pin 'home'. If necessary, jack up each wheel & rotate slightly to allow re-engagement of pin.

**4.7.3 CRANEAGE**

- 1) Observe all of the limitations relating to straps and chains stated above under 'Transporting'. (4.7.1)
- 2) When utilising the designated lifting points never apply a 'snatch' load, i.e. lift slowly to take up the load before raising. Similarly, do not drop machine when positioning after lifting.
- 3) If the machine is to be lifted by crane, use the designated lifting points and observe the recommendations regarding spreader beams. Individual drawings are available for each machine type, on request. (See list below.)

D81790
D81795
D81980

HR15/17 4x4/Hybrid MK2
HR15N/17N
HR21 MK2

4.7.4 STORAGE

If being stored for any length of time without use, then the machine should be thoroughly inspected for the following:-

- 1) Grease all bearings /slides, worm drives, etc.

- 2) If machine is to be left on an incline, chock wheels to prevent creep.
- 3) Check batteries for state of charge, damage, dirt, etc. Ensure batteries are **fully charged** before storage. If no use of the platform is intended, an occasional "top-up" charge of the batteries will serve to equalise their charge level. **Never leave in a state of discharge for any length of time.** Refer to HR21 MK2 Service Manual for further information.
- 4) Leave battery disconnect switch in **OFF** position to prevent discharge of batteries through leakage.
- 5) If machine is to be left outside or in a hostile environment, cover with suitable weatherproof media to prevent deterioration.

4.7.5 SETTING TO WORK

Before use each day and at the beginning of each shift the machine shall be given a visual and functional test including, but not limited to, the following

- 1) Check all lubrication points for adequate application of grease, oil etc.
- 2) Inspect all threads for ease of operation - especially descent valves, brake release valve etc.
- 3) Check level and quantity of oil. Remove any contaminants - water, etc.
- 4) Check batteries for electrolyte and state of charge.
- 5) Check electrics for damage and insulation.
- 6) Using ground controls, cycle machine over complete envelope in accordance with the Operating Instructions. Cure any defects.
- 7) Ensure that all safety devices and controls operate in accordance with the instructions.
- 8) If necessary, perform a load test to establish the machine stability before putting the machine to work.
- 9) On completion of an extended period of road transport, the machine might need additional inspection to identify any transit degradation, which could render the machine unsafe. Perform a P.D.I. inspection on the unit before it enters service. Record any faults found and rectify them immediately.
- 10) If left un-attended for an extended period, it is likely that the hydraulic cage levelling will become un-pressurised. Normal operation is then lost, with a noticeable delay in the forwards or backwards motion as the booms move. To restore normal function, operate the cage-levelling function at the Ground Control Station, the cage needs to be fully levelled forwards and backwards. When the system has been charged in both directions, the cage levelling function should be restored. Repeat the procedure as described above until the movements are smooth and un-interrupted. If in doubt, contact our Service Department for further advice.

Niftylift Limited is not liable for any third party damage caused during transport. Careful attention to correct procedures will prevent many of the small snags that can happen in transit. Re-work is both expensive and time consuming. A defective machine arriving at the place of work is a poor advertisement for our product, the company's reputation and those of our dealers and clients. The responsibility for safe and damage-free transport rests with the haulier or their representatives.

5 Emergency Controls

5.1 GENERAL

CHECKING THE OPERATION OF THE EMERGENCY CONTROLS EVERY DAY AND/OR BEFORE EACH SHIFT IS AN ESSENTIAL PART OF THE OPERATOR'S DUTIES



The operator and all ground personnel must be thoroughly familiar with the location and operation of the emergency controls.

5.2 IN THE EVENT OF AN INCAPACITATED OPERATOR

Turn the key switch at the ground control station to **ground** (central position).
Manoeuvre the machine using the ground controls as described previously in Section 4.2.

5.3 IN THE EVENT OF MACHINE FAILURE

If all machine power is lost, the **manual hand pump** can be used to provide the hydraulic power to manoeuvre the machine. If initial movement of the machine allows the master alarm to reset, normal controls will be available. This is then the fastest method of lowering the platform to the ground.

Note: If the machine is fitted with a cage overload system, and the cage comes into contact with a fixed object whilst operating at height, this would be detected as an overload condition. All power to the machine controls would be lost, requiring the machine to be recovered using the **Manual Hand Pump** or **Auxiliary Descent Pump**. It is sufficient for the cage to be manoeuvred away from the collision point to re-set the cage weigh mechanism, thereby restoring normal machine operation. The cage can now be lowered using the controls as described previously in Section 4.3.

FOLLOWING AN EMERGENCY DESCENT RECOVERY OF THE PLATFORM, FULLY EXTEND AND RETRACT ALL CYLINDERS FROM GROUND CONTROL STATION BEFORE USING THE MACHINE.



5.4 INCIDENT NOTIFICATION

It is a mandatory requirement that any accident or incident involving a Niftylift, regardless of whether any party received injury or property was damaged is reported by telephone directly to Niftylift. Failure to do so may render any warranty on the machine void.

6 Responsibilities

6.1 CHANGES IN OWNERSHIP

When a change of ownership of a Niftylift occurs, it shall be the responsibility of the seller to notify Niftylift directly of the unit, model and serial number and the name and address of the new owner within 60 days. This important step is required so that any relevant Technical Bulletins are able to reach the registered owner of each machine without delay. Please note warranties are not transferable.

6.2 MANUAL OF RESPONSIBILITIES (USA only)

You are required by ANSI/SIA 92.5 2006, to read and understand your responsibilities before you use or operate this aerial platform. Please read the enclosed document, as failure to do so could result in death or serious injury. Wherever any contradiction may appear, the Manual of Responsibilities shall take precedence over all other documents.

Operating & Safety Instructions**6.3 INSPECTION/SERVICE/PRE-HIRE CHECK LIST****MACHINE SERIAL NO** _____

ADMINISTRATION	PASS	FAIL	
Daily, Weekly, Monthly checks carried out as outlined in manufacturers Operating and Safety Manual?			
Machine has valid LOLER Certificate? (UK only)			
TOWING	PASS	FAIL	N/A
Check brakes are released or...			
Check wheel gearboxes disengage when required			
AXLES, WHEELS AND BRAKES			
Axles are secure			
Wheels are secure, tyre condition acceptable			
Wheel alignment and tracking correct			
Tyre pressure correct			
Wheel nut torque correct			
Operation of front and rear steer functions			
Operation of suspension dampers			
Pivot pins and swing bolts secure			
BASE			
Operation of Emergency Stop button			
Operation of Base control valve and buttons			
Operation of all booms over full range			
Platform maintains level over full range			
Hoses not tight, kinked or fouled			
Operation of manual hand pump			
Operation of auxiliary descent pump			
Operation of tilt sensor when driven elevated on slope $>4^{\circ}$			
Pivot pins and swing bolts secure			
BOOMS/LINKS			
Inspect for damaged, distorted or loose components			
Wear pads present and secure			
Cylinders are silent and not fouling during operation			
Cylinders do not drift when machine is switched off			
Operation of micro-switches i) Links ii) Luffing iii) Telescope iv) Flyboom			
Chain inspection - Correctly tensioned, damage etc.			
Energy chain correct and secure over tele function range			
Bushes (Condition check)			
Pivot pins and swing bolts secure			

nifty Height Rider/SP Series
Operating & Safety Instructions

PLATFORM	PASS	FAIL	N/A
Operation of Emergency Stop button			
Operation of SiOPS (Refer to Section 4.3.5)			
Operation of control valve and control panel buttons/switches			
Operation of all booms over full range			
Operation of Footswitch			
Platform levelling over full range			
Slewing smooth over full range			
Condition of harness points			
Condition and operation of entry/exit drop gate			
POWER SYSTEM			
Engine - Refer to Pre-Operation and Maintenance sections in engine manufacturers Operating Manual as supplied			
All cables and terminals secure			
All hose connections secure			
Charger/control box secure			
Battery secure			
Hydraulic oil level			
SLEWING			
Slew gearbox and motor are secure			
Slew wheel bolts secured			
Slew guards secure			
FINISH			
Serial plate against documentation			
Check all decals in place and legible			
Canopies in place and secure			
Check all guards are in place and in good condition			
Grease nipples (Slew ring, Steer pins)			
LEAK CHECK			
Hydraulic Cylinders (Lift, Telescope, Levelling)			
Control valves			
Check valves			
Power system pump			
Filters			
Hand pump			
Slew motor			
Hydraulic Hose connections and fittings			

Note; Environmental factors and usage amount will affect the type of checks and also the frequency of inspection intervals.

nifty Height Rider/SP Series

Operating & Safety Instructions

Comments, remedial work required etc;

INSPECTED BY: _____

DATE: / /

Appendix A

Application specific error codes

For more comprehensive error information please refer to the HR21 MK2 Service Manual.

Error Code	Description	Action
01A10000	There is a problem with the signals from the normally closed and normally open contacts of the Keyswitch to the PLC	Ensure contact blocks are securely in position. Check Keyswitch wiring from the switch contacts to the PLC
01A20000	There is a problem with the signals from the normally closed and normally open contacts of the Base E-Stop to the PLC	Ensure contact blocks are securely in position. Check Base E-Stop wiring from the switch contacts to the PLC
01A30000	There is a problem with the signals from the normally closed and normally open contacts of the Cage E-Stop to the PLC	Ensure contact blocks are securely in position. Check Cage E-Stop wiring from the switch contacts to the PLC
01A40000	There is an error with the signals from the Load Sensing system	Check the Load Sensing PCB is functioning and EN and ALM are opposite. Check wiring from the Load Sensing PCB to the PLC
01A50000	There is a problem with the signals from the normally closed and normally open contacts of the Booms Down Switch to the PLC	Check Booms Down Switch wiring from the switch contacts to the PLC
01A60000	There is a problem with the signals from the normally closed and normally open contacts of the Telescope Switch to the PLC	Check Telescope Switch wiring from the switch contacts to the PLC
01A70000	There is a problem with the Mode Select Switch	Check the wiring from the Mode Select Switch to the Cage Node. Replace the Mode Select Switch
01A80000	The Cage Rotate Switch is sending Left and Right signals at the same time	Check the Cage Rotate switch wiring. Replace the Cage Rotate switch

Operating & Safety Instructions

Error Code	Description	Action
01A90000	There is a problem with the Override Switch	Check the wiring from the Override Switch to the PLC Replace the Override Switch
01AA0000	The steer switch is sending a left and right signal at the same time	Check the wiring to the Drive Joystick. Replace the Drive Joystick
01AB0000	The pressure transducer is reporting a value that is lower than its allowable range	Check the wiring from the Pressure Transducer to the PLC Ensure the pressure transducer is securely installed into the valve block and the electrical connector is plugged in
01AC0000	The pressure transducer is reporting a value that is greater than its allowable range	Check the wiring to the Pressure Transducer
01AD0000	The drive pressure in elevated mode is too high	Avoid sharp changes of direction. Contact a Niftylift approved service centre
01B10000	The Links Paddle was out of the neutral position before the Green Button or Footswitch was pressed	Return the Links Paddle to the neutral position and release the Green Button and Footswitch. Press the Green Button or Footswitch and then move the Links Paddle to operate Links
01B20000	The Luffing Paddle was out of the neutral position before the Green Button or Footswitch was pressed	Return the Luffing Paddle to the neutral position and release the Green Button and Footswitch. Press the Green Button or Footswitch and then move the Luffing Paddle to operate Luffing
01B30000	The Slew Paddle was out of the neutral position before the Green Button or Footswitch was pressed.	Return the Slew Paddle to the neutral position and release the Green Button and Footswitch. Press the Green Button or Footswitch and then move the Slew Paddle to operate Slew

Error Code	Description	Action
01B40000	The Telescope Paddle was out of the neutral position too long before the Green Button or Footswitch was pressed	Return the Telescope Paddle to neutral and release the Green Button and Footswitch. Press the Green Button or Footswitch and then move the Telescope Paddle to operate Telescope. Check the paddle returns to the neutral position when released. If not, replace the paddle
01B50000	The Fly Paddle was out of the neutral position before the Green Button or Footswitch was pressed	Return the Fly Paddle to the neutral position and release the Green Button and Footswitch. Press the Green Button or Footswitch and then move the Fly Paddle to operate Fly
01B60000	The Drive Joystick was out of the neutral position before the Green Button or Footswitch was pressed	Return the Drive Joystick to the neutral position and release the Green Button and Footswitch. Press the Green Button or Footswitch and then move the Drive Joystick to operate drive
01C20000	The Joystick and PLC are not communicating	Ensure Joystick is plugged in. Check power and CAN Bus connections to the Drive Joystick
01C30000	The Cage Node and PLC are not communicating	Ensure Cage Node is plugged in Check power supply and CAN Bus connections to the Cage Node
01C40000	The Motor Controller and PLC are not communicating	Ensure the Motor Controller is plugged in. Check power supply and CAN Bus connections to the Motor Controller
01C50000	The Engine and PLC are not communicating	Check power supply and CAN Bus connections to the Engine Node
01C80000	The Cage Screen and PLC are not communicating	Ensure screen is plugged in. Check power supply and CAN Bus connections to the Cage Screen
01C90000	The Base Screen and PLC are not communicating	Ensure screen is plugged in. Check power supply and CAN Bus connections to the Base Screen

Operating & Safety Instructions

Error Code	Description	Action
01CF0000	The Chassis Inclination Sensor and PLC are not communicating	Ensure Chassis Inclination Sensor is plugged in. Check power supply and CAN Bus connections to the Chassis Inclination Sensor
01D10000	There is potentially a fault with the Footswitch, Base Green Button, Cage Green Button	Release the Base Green Button, Cage Green Button, and Footswitch and ensure they are clear from obstructions. Check the wiring
01D20000	The drive joystick trigger is: being held too long before motion is requested; obstructed; or it has failed	Hold trigger for only a few seconds prior to requesting motion. Remove objects that are obstructing the trigger. Replace the drive joystick
01D30000	The Chassis Inclination Sensor is at an angle side to side across the machine that is too great to allow zero to be set	Move the machine to firm level ground (e.g. Concrete factory floor) before entering the code to zero the Chassis Inclination Sensor
01D40000	The Chassis Inclination Sensor is at an angle between the front and rear of the machine that is too great to allow the zero to be set	Move the machine to firm level ground (e.g. Concrete factory floor) before entering the code to zero the Chassis Inclination Sensor
01D50000	The Chassis Inclination sensor requires calibration (X)	Calibrate the inclination sensors using the machine screen in the base control position.
01D60000	The Chassis Inclination sensor requires calibration (Y)	Calibrate the inclination sensors using the machine screen in the base control position.
01D70000	The Steer position sensor requires calibration	Calibrate the steer angle sensor using the machine screen in the base control position.
01E10000	There is a problem with the signal from the Luffing Paddle in the cage	Return the Luffing Paddle to neutral and attempt to operate Luffing again. Check the connector to the Luffing Paddle is secure. Replace the Luffing Paddle

***nifty* Height Rider/SP Series**
Operating & Safety Instructions

Error Code	Description	Action
01E20000	There is a problem with the signal from the Links Paddle in the cage	Return the Links Paddle to neutral and attempt to operate Links again. Check the connector to the Links Paddle is secure. Replace the Links Paddle
01E30000	There is a problem with the signal from the Slew Paddle in the cage	Return the Slew Paddle to neutral and attempt to operate Slew again. Check the connector to the Slew Paddle is secure. Replace the Slew Paddle
01E40000	There is a problem with the signal from the Fly Paddle in the cage	Return the Fly Paddle to neutral and attempt to operate Fly again. Check the connector to the Fly Paddle is secure. Replace the Fly Paddle
01E50000	There is a problem with the signal from the Telescope Paddle in the cage	Return the Telescope Paddle to neutral and attempt to operate Telescope again. Check the connector to the Telescope Paddle is secure. Replace the Telescope Paddle
01E60000	There is a problem with the signal from the Drive Joystick in the cage	Return the Drive Joystick to neutral and attempt to operate the Joystick again. Check the connector to the Drive Joystick is secure. Replace the Drive Joystick
01F10000	There is a problem with the Motor Controller	Investigate the flashing LED on the Motor Controller for further diagnosis
01F20000	A software parameter is missing or not valid	Cycle the power to the machine
01F30000	The serial number of the machine is incorrect	Check the machine serial plate. Contact a Niftylift approved service centre
01F40000	The PLC is set to download	Move the Test Jumper in the Main Control Box to 0 V (Zero volts)
01F50000	The engine has gone into a protect state	This could be because the fuel level is low, the oil pressure is low or the coolant temperature is too high
01F60000	The Hybrid battery pack temperature is too high	Allow the machine to cool

Appendix B

Safety Related Parts of the Control System (SRP/CS)

The Niftylift control system has been designed and validated according to the required standards. The table below lists the safety related parts of the control system and the level to which they have been approved.

The performance level (PL) of each SRP/CS is specified by BS EN 280:2013+A1 2015 section 5.11 Table 5.

Safety Related Part of the Control System (SRP/CS)	Approval (Standard, Performance Level)
A1 Prevent travel above inclination limit	ISO 13849-1:2008 PL c
A2 Limitation of travelling speed	ISO 13849-1:2008 PL c
A3 Load sensing system	ISO 13849-1:2008 PL d
A4 Platform levelling	ISO 13849-1:2008 PL c
A5 Interlocking of control positions	ISO 13849-1:2008 PL c
A6 Prevent movements of load holding cylinders in case of pipe failure	ISO 13849-1:2008 PL c
A7 Interlocking of travel controls	ISO 13849-1:2008 PL b
A8 Emergency Stop	BS EN ISO 13850:2015 PLd/c

A1 PREVENT TRAVEL ABOVE INCLINATION LIMIT

The inclination interlock or Tilt System is PL c in accordance to with ISO 13849-1:2008 as required by BS EN 280:2013+A1 2015.

1.The limits of the safety-related parts to the category selected and any fault exclusions;

The tilt interlock is only active when the telescoping booms are lifted up off the boom rest such that the boom switch is actuated.

The boom switch relies on the electrical contacts opening allowing the tilt system to permit drive within the rated angle.

The opening of the contacts is forced by the use of the spring contained within the booms down switch assembly. **Proper maintenance and daily safety checks to be observed**

The boom switch cannot be overridden to bypass the tilt system other than by demounting the switch with the use of tools. **Reasonably foreseeable misuse**

If the boom switch is removed or if it is not maintained in accordance with the appropriated documentation the tilt system may not function in compliance with the requirements as a PL c device.

2.The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

Maintenance must only be carried out by appropriately trained and competent persons.

3.The effects of deviations from the specified performance on the safety function(s);

If the tilt interlock does not function as intended it is possible that the Niftylift may encounter slopes for which it is not rated.

If the Niftylift encounters slopes beyond the rating as specified on the serial plate the product may occur instability.

If the product becomes unstable, damage to the Niftylift, other equipment and properties, injury or loss of life of the operator and surrounding persons may be a risk.

4.Clear descriptions of the interfaces to the SRP/CS and protective devices;

The tilt system comprises of a primary device the “tilt sensor” the booms down switch, and control PCBs, and protective devices, for example solenoid operated hydraulic valves or contactors.

If the drive forward or backwards functions are selected when on the boom rest, the drive functions will be available regardless of angle of inclination.

If the drive forward or backwards functions are selected when off the boom rest, the output from the tilt sensor not being present will deny drive functions.

5.Response time

The tilt sensor is active at all times providing the correct signal in relation to the angle of inclination of the chassis. In the event of encountering an angle of inclination greater than allowable the system will prevent drive functions from being performed until the booms have been lowered on to the boom rest and the angle of inclination has been corrected.

6.Operating limits (including environmental conditions);

All components within the tilt interlock are rated to the environmental conditions acceptable for the machine; refer to Section 2.2.

7.Indications and alarms;

Tilt alarm

The action of the tilt alarm will cause the klaxon to sound and will be indicated by the red warning light on the base and cage location, if the booms are raised and the allowable tilt limit is detected.

8.Muting and suspension of safety functions;

While the tilt sensor is always active the drive interlock is suspended while the booms are on the boom rest. The angle of inclination having been exceeded will be indicated via warning lights regardless of the boom position.

9.Control modes;

The tilt system has no user controllable modes of operation.

Operating & Safety Instructions*10. Maintenance; Maintenance check lists;*

Normal maintenance

- Visual check of transducers, board (box) and connection wires.
- Check of power supply to verify it is correct.
- Check of the equipment correct operation, by simulating a locked condition and correspondent rearming. See "Means for easy and safe trouble shooting"
- Check correct operation of the boom switch.

The tilt sensor will not normally require special maintenance. Should special maintenance be required please observe the following precautions.

- Cut off power supply before every check or replacement.
- Do not weld on machine structure before removing power supply (positive and negative) and detaching boxes from vehicle frame or possible connections towards vehicle frame.
- Provide suitable mechanical protections for connection wires, paying particular attention for transducers.
- Do not place board, transducers or cabling close to sources of heat, electromagnetic interferences or power transmissions.
- Do not touch directly boards, transducers and boxes with flushing or degreaser fluids under pressure.
- Do not hole the board box.
- Seal the box and/or the panel who contains the electronic board, to reveal any not authorized access or tampering.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

If parts require replacement only replace the whole such as Tilt Sensor, Safety Switch, PLC or Hydraulic valve block.

Do not attempt to open the tilt sensor or replace components soldered to any PLC.

Do not attempt maintenance of hydraulic components i.e. replace seals or internal component.

Only Niftylift original and supplied parts shall be used.

12. Means for easy and safe trouble shooting;

To check the operation of the tilt sensor system

With booms slightly raised, drive onto a slope equal to the rated angle of the machine. The machine brakes should halt the machine as soon as the level is reached.

13. Information explaining the applications for use relevant to the category to which reference is made;

Not applicable.

14. Checking test intervals where relevant.

Check the operation of the tilt sensor system to be made at the beginning of every duty cycle.

A2 LIMITATION OF TRAVELLING SPEED

The limitation of travelling speed interlock, also known as the elevated drive speed system, is PL c in accordance with ISO 13849-1:2008 as required by BS EN 280:2013+A1 2015.

1. The limits of the safety-related parts to the category selected and any fault exclusions;

The elevated drive speed system is only active when the telescoping booms are lifted up off the boom rest such that the boom switch is actuated or the telescopic sections are telescoped out such that the telescopic switch is actuated.

Depending on the boom/tele switch contacts the PLC controls if elevated drive speed is selected.

The boom switch actuator is actuated by the use of the spring contained within the booms down switch assembly. Proper maintenance and daily safety checks to be observed.

The boom switch cannot be overridden to bypass the elevated drive system other than by demounting the switch with the use of tools.

If the boom or tele switch is removed or if it is not maintained in accordance with the appropriated documentation the elevated drive speed system may not function in compliance with the requirements as a PL c device.

2. The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

Maintenance must only be carried on by appropriately trained and competent persons.

3. The effects of deviations from the specified performance on the safety function(s);

If the elevated drive speed interlock does not function as intended it is possible that the Niftylift may experience dramatic dynamic effects which may adversely affect the stability of the product.

If the product becomes unstable, damage to the Niftylift, other equipment and properties, injury or loss of life of the operator and surrounding persons may be a risk.

4. Clear descriptions of the interfaces to the SRP/CS and protective devices;

The elevated drive speed interlock consists of the booms down switch and the telescope switch control a PLC and solenoid operated hydraulic valve.

If the drive forward or backwards functions are selected when the booms are stowed the elevated drive valve will be energised allowing the full speed drive functions. If the drive forward or backwards functions are selected when off the boom rest the output from the PLC is required to energise the elevated drive valve to reduce the drive speed.

5. Response time

The boom switch is active at all times providing the correct signal in relation to the position of the booms. With the booms in the raised position or the telescopic sections are extended the system will prevent high speed drive functions from being performed until the booms have been lowered or telescoped in.

Operating & Safety Instructions

6. Operating limits (including environmental conditions);

All components within the elevated drive speed are rated to the environmental conditions acceptable for the machine; refer to Section 2.2.

7. Indications and alarms;

There are no indicators or alarms to show that the Niftylift is under the control of the elevated drive speed interlock.

8. Muting and suspension of safety functions;

It is not possible to suspend the operation of the Elevated drive speed interlock with the booms raised or the telescope sections extended.

9. Control modes;

The elevated drive speed interlock has no user controllable modes of operation.

10. Maintenance; Maintenance check lists;

Normal maintenance

- Check correct operation of the boom and telescope switch.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

If parts require replacement only replace the complete item such as Safety Switch, PLC or Hydraulic valve block.

Do not attempt to open the booms switches, other than to check the condition of the wiring to the switches.

Do not attempt maintenance of hydraulic components i.e. replace seals or internal component.

Only Niftylift original and supplied parts shall be used.

12. Means for easy and safe trouble shooting;

To check the operation of the elevated drive speed system

- 1) Ensure that the Niftylift has sufficient clearance in all directions to drive for a minimum distance to ascertain that the elevated drive speed is correct.
- 2) Power on the Niftylift and select the cage control location.
- 3) From the cage control elevate the links booms sufficient to remove the telescope sections from the boom rest such that the boom switch is actuated.
- 4) By the use of the drive forward and backwards functions in turn, depress the joystick trigger and depress the joystick in the desired direction.
- 5) Observe that the speed of the drive functions is no more than 1km/h. This can be characterised as a very slow walking pace.
- 6) Release the joystick to cease driving operations.
- 7) Repeat steps 1) to 6) with the telescope sections extended enough to actuate the telescope switch

13. *Information explaining the applications for use relevant to the category to which reference is made;*

Not applicable

14. *Checking test intervals where relevant.*

Check the operation of the elevated drive system to be made at the beginning of every duty cycle.

Operating & Safety Instructions**A3 LOAD SENSING SYSTEM**

The Load sensing system is PL d in accordance to with ISO 13849-1:2008 as required by BS EN 280:2013+A1 2015

1. The limits of the safety-related parts to the category selected and any fault exclusions;

The load sensing system is activated whenever a green button or footswitch input is given to the PCB. The sensing system is a two-channel device which takes the input from a single load cell bridge on the cage load cell. The actual cage load is determined, and in the case of an overload, the alarm will sound and the output signal is lost.

The loss of the output signal is converted into two separate signals, one of which is used to isolate Channel 1 output (EN) and the other to isolate the Channel 2 output. (ALM). **Proper maintenance and daily safety checks to be observed.**

On initial set-up the machine must be zero loaded to allow the 'Tare' function to register the no-load condition. Following that a calibrated test load is put into the cage to set the upper limit. Proper adherence to the zero set point and the correct test load must be taken to ensure the load sensing system is working correctly. It is possible to apply the overload to the machine in the rest position, and then only to detect this on the next application of the command signal. If the machine has been in the elevated position the consequences of this would be more significant than if the machine were stowed.

Reasonably foreseeable misuse

2. The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

Maintenance must only be carried on by appropriately trained and competent persons, who are conversant with all modes of operation, speeds and characteristics of this model.

3. The effects of deviations from the specified performance on the safety function(s);

If the load sensing system does not function as intended it is possible that the Niftylift may encounter overloads for which it is not rated.

If the Niftylift encounters loads beyond the rating as specified on the serial plate the product may occur instability.

If the product becomes unstable, damage to the Niftylift, other equipment and properties, injury or loss of life of the operator and surrounding persons may be a risk.

4. Clear descriptions of the interfaces to the SRP/CS and protective devices;

The load moment control system comprises of a primary device the "load sensor" and a PLC, and protective devices, for example solenoid operated Mater dump valves.

If the load sensing system cuts out, an alarm will sound and a clear indication of visual overload will be given at each operating position. The system will not re-set until the overload has been removed, by recommendation of reducing the overload in a safe manner.

5. Response time;

The Load sensing system is active all the time the green button or footswitch is depressed, the application of an overload will be detected within 4 seconds to cater for transient loads and acceleration forces. The alarm and visual indication will continue to sound as long as the machine is overloaded and the command signal is being applied. Removal of the overload by reduction of the applied load will take the cage weight below the threshold for activation as there is 95% hysteresis in the system. Once restored the load system will function as before and no re-calibration will be necessary.

6. Operating limits (including environmental conditions);

All components within the load sensing system are rated to the environmental conditions acceptable for the machine; see **Section 2.2**.

7. Indications and alarms;

The action of the cage overload detection will cause the klaxon to sound and will be indicated by the red warning light on the base and cage location, only as long as the green button or footswitch is continued to be depressed.

8. Muting and suspension of safety functions;

In the case of the overload being detected the alarm can be silenced by releasing the green button or footswitch. Suspension of the function will continue until the overload has been safely removed.

9. Control modes;

The load sensing system has no user controllable modes of operation, other than by use of the calibration tool.

10. Maintenance; Maintenance check lists;

Normal maintenance

- Visual check of connection wires.
- Check of power supply to verify it is correct.
- Check of the equipment correct operation, by simulating an overload condition and correspondent re-setting. See "Means for easy and safe trouble shooting"

The load sensor will not normally require special maintenance

Should special maintenance be required please observe the following precautions.

- Cut off power supply before every check or replacement.
- Do not weld on machine structure before removing power supply (positive and negative) and detaching boxes from vehicle frame or possible connections towards vehicle frame.
- Provide suitable mechanical protections for connection wires, paying particular attention for transducers.
- Do not place board, transducers or cabling close to sources of heat, electromagnetic interferences or power transmissions.
- Do not touch directly boards, transducers and boxes with flushing or degreaser fluids under pressure.
- Do not hole the board box.
- Seal the box and/or the panel who contains the electronic board, to reveal any not authorized access or tampering.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

If parts require replacement only replace the whole such as Load Sensor, PLC, PCB or Hydraulic valve block.

Do not attempt to open the load sensing PCB or replace components soldered to any PCB.

Do not attempt maintenance of hydraulic components i.e. replace seals or internal component.

Only Niftylift original and supplied parts shall be used.

12. Means for easy and safe trouble shooting;

To check the operation of the load sensor system

1. Power on the Niftylift and select the base control location.
2. Allow the power circuits to cycle and ensure the machine is ready for the command signal.
3. Press the base green button and observe that the machine is ready to function with no load in the cage. (Machine runs, pump flow is available for machine functions.)
4. Select the Cage control position and mount into the cage.
5. Enable the cage controls and then press the cage green button or foot switch to enable the machine functions. (Machine runs, pump flow is available for machine operation.)
6. Add sufficient load to the cage to exceed the safe working load. Press the green button or foot switch and observe that the cage overload system brings in the alarm and halts all machine movements.
7. Remove the overload to below the threshold for safe working load and observe that the cage load control automatically re-sets and restores all machine functions.
8. Power off the Niftylift.

13. Information explaining the applications for use relevant to the category to which reference is made;

Not applicable

14. Checking test intervals where relevant.

Check the operation of the load sensing system to be made at the beginning of every duty cycle.

15. Proof testing

This two channel system must be proof tested to identify unrevealed failures every six months by a competent person with appropriate safety function experience.

Load sensing system – Prime mover

Test 1

1. Identify the two solenoid valves maintaining the safety function for each channel using the machine electrical and hydraulic schematics – P27646 – V2 and V5.
2. Stow the machine and remove the coil from V2
3. Attempt to operate the booms via the green button
4. Fit the coil back onto V2
5. Repeat steps 1-4 but for V5

Pass criteria - If the booms do not operate the system is functioning correctly.

Fail criteria – If the booms move there is a previously undetected fault with the system and the Niftylift must not be used until this fault has been repaired.

Repair must be carried out by a competent person(s) with appropriate safety function experience.

Load sensing system – Auxiliary pump

Test 2

1. Identify the two solenoid valves maintaining the safety function for each channel using the machine electrical and hydraulic schematics – P27646 – V2 and V3.
2. Stow the machine and remove the coil from V2
3. Attempt to operate a boom function using the override button
4. Fit the coil back onto V2
5. Repeat steps 1-4 but for V3

Pass criteria - If the booms do not operate the system is functioning correctly.

Fail criteria – If the booms move there is a previously undetected fault with the system and the Niftylift must not be used until this fault has been repaired.

Repair must be carried out by a competent person(s) with appropriate safety function experience.

Operating & Safety Instructions**A4 PLATFORM LEVELLING**

The Platform levelling system is PL c in accordance to with ISO 13849-1:2008 as required by BS EN 280:2013+A1 2015

1.The limits of the safety-related parts to the category selected and any fault exclusions;

The Platform levelling system comprises of a load holding device mounted to the slave levelling cylinder.

2.The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

In the event of a hose failure ensure a recovery plan is in place that does not require the movement of the luffing booms as the angle of the cage will not be maintained. See effect of deviations from the specified performance below.

Maintenance must only be carried on by appropriately trained and competent persons.

3.The effects of deviations from the specified performance on the safety function(s);

If the levelling system of the product does not function as intended the angle of the cage may not be maintained.

If the angle of cage is not maintained there is an increased risk of ejection of tools and equipment from the cage;

In the event of the operator or other occupants of the cage not using the required safety equipment they may be ejected from the cage and serious injury or death may occur.

There is a load holding device contained within the assembly of the slave levelling cylinder such that if a hose fails the cage position is maintained until the operator can be recovered from the cage.

4.Clear descriptions of the interfaces to the SRP/CS and protective devices;

The levelling system comprises of two hydraulic cylinders and interconnecting hoses.

One is referred to as the Master levelling cylinder

The other is referred to as the Slave levelling cylinder.

In normal operation when the luffing booms are elevated the master levelling cylinder responds to the movement of the booms and causes a transfer of hydraulic fluid to the appropriate side of the slave levelling cylinder.

This transfer of hydraulic fluid maintains the level aspect of the cage.

5.Response time

The Levelling system is a direct acting hydraulic system and as such the response time is near instantaneous.

6. Operating limits (including environmental conditions);

All components within the platform levelling system are rated to the environmental conditions acceptable for the machine; see **Section 2.2**.

7. Indications and alarms;

There are no indicators or alarms to show that the Niftylift levelling system is functioning.

8. Muting and suspension of safety functions;

It is not possible to suspend the operation of the levelling system.

9. Control modes;

The levelling system has two modes of operation

- 1) Normal movements of the luffing booms cause the system to constantly adjust the cage angle to keep it level.
- 2) Manual adjustment to account for drift of the system over time.

10. Maintenance; Maintenance check lists;

Normal maintenance

- Removal of air from the hydraulic system if the product is left unused for long periods of time.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

If parts require replacement only replace the whole components such as hoses, hydraulic cylinders or load holding and over centre valve.

Do not attempt maintenance of hydraulic components i.e. replace seals or internal component.

Only Niftylift original and supplied parts shall be used.

12. Means for easy and safe trouble shooting;

Elevate the luffing booms and check that the cage remains level. If the cage does not remain level the system should be serviced by trained persons fully conversant with the function of the system.

13. Information explaining the applications for use relevant to the category to which reference is made;

Not applicable

14. Checking test intervals where relevant.

Check the operation of the cage levelling system to be made at the beginning of every duty cycle.

A5 INTERLOCKING OF CONTROL POSITIONS

The interlocking of the control positions is PL c in accordance to with ISO 13849-1:2008 as required by BS EN 280:2013+A1 2015

1. The limits of the safety-related parts to the category selected and any fault exclusions;

The physical interlocks between the multiple control positions are controlled through primarily electrical means such that neither position takes sole command unless selected. The alternate control position is then rendered inoperative by isolation of that control circuit. **Proper maintenance and daily safety checks to be observed.**

Since the physical installation of the electrical contacts is the means by which the control circuit operates it is imperative that the functionality is retained. If the internal wiring is interfered with the control isolation could be lost or altered in a way that promotes a dangerous mode of operation. **Reasonably foreseeable misuse**

2. The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

Maintenance must only be carried on by appropriately trained and competent persons, who are conversant with all modes of operation, speeds and characteristics of this model.

3. The effects of deviations from the specified performance on the safety function(s);

If the interlocking of the control positions does not function as intended it is possible that the Niftylift may allow modes of operation that render it potentially dangerous.

If the controls do not remain independent in their operation, damage to the Niftylift, other equipment and properties, injury or loss of life of the operator and surrounding persons may be a risk.

4. Clear descriptions of the interfaces to the SRP/CS and protective devices;

Each control position is capable of being energised by means of a key operated 'mode selector' which electrically isolates the other circuit when one is selected. The reliability of this function depends on the correct device operator in conjunction with the appropriate contact and internal wiring.

5. Response time

Operation of the mode selector key switch is immediate. Control authority is transferred over and no residual power functions remain with the alternate control position, other than gravity descent (if used.)

6. Operating limits (including environmental conditions);

All components within the control interlock system are rated to the environmental conditions acceptable for the machine; see **Section 2.2.**

7. Indications and alarms;

None, other than by key position.

8. Muting and suspension of safety functions;

None.

9. Control modes;

The control circuit will permit independent operation of either control position with the key positions: OFF, BASE and Cage.

10. Maintenance; Maintenance check lists;

Normal maintenance

- Visual check of switch operators, (Key switch) and connection wires.
- Check of power supply to verify it is correct.
- Check of the equipment correct operation, by selection of the alternate control position and then checking that the green button is inert at the non-selected position.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

Individual parts of the control devices can be replaced, ensuring like-for-like exchange of parts, security of the wiring and polarity of components if applicable (Diode outputs etc.)

Only Niftylift original parts shall be used.

12. Means for easy and safe trouble shooting;

To check the operation of the load sensor system.

1. Power on the Niftylift and select the base control location.
2. Allow the power circuits to cycle and ensure the machine is ready for the command signal.
3. Press the base green button and observe that the machine is ready to function with no load in the cage. (Machine runs, pump flow is available for machine functions.)
4. Leave the base key in the ground control position and mount into the cage.
5. Enable the cage controls and then press the cage green button or foot switch to enable the machine functions. Check that no controls are active and that no functions are permitted with the key in the 'ground' control position.
6. Have the base key switch position altered to the Cage position. Check that the control functions are now transferred to the cage, and that all controls are active.
7. Dismount from the cage and check the ground controls are now inoperative. All checks are then complete.
8. Power off the Niftylift.

13. Information explaining the applications for use relevant to the category to which reference is made;

Not applicable

14. Checking test intervals where relevant.

Check the operation of the control position interlock to be made at the beginning of every duty cycle.

A6 PREVENT MOVEMENTS OF LOAD HOLDING CYLINDERS IN CASE OF PIPE FAILURE

The load holding system is PL c in accordance to with ISO 13849-1:2008 as required by BS EN 280:2013+A1 2015

1.The limits of the safety-related parts to the category selected and any fault exclusions;

The load holding system comprises of a load holding device mounted to the cylinder.

2.The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

In the event of a hose failure ensure a recovery plan is in place that does not require the movement of the affected cylinder. A safe route of recovery might involve the replacement in-situ of the failed hose before further movement of the machine is possible.

Maintenance must only be carried on by appropriately trained and competent persons.

3.The effects of deviations from the specified performance on the safety function(s);

If the load holding system of the product does not function as intended the angle of the booms may not be maintained.

If the angle of cage is not maintained there is an increased risk of ejection of tools and equipment from the cage;

In the event of the operator or other occupants of the cage not using the required safety equipment they may be ejected from the cage and serious injury or death may occur.

There is a load holding device contained within the assembly of the slave levelling cylinder such that if a hose fails the cage position is maintained until the operator can be recovered from the cage.

4.Clear descriptions of the interfaces to the SRP/CS and protective devices;

The load holding system comprises of a pilot operated over centre valve on each load holding cylinder.

The opening of the load holding valve is dependent on the application of a pilot pressure in the descent line to bring the machine down. Excessive over pressure either by overload or thermal expansion can induce an over centre pilot descent until the excess pressure condition is removed.

5.Response time

The load holding system is a direct acting hydraulic system and as such the response time is near instantaneous.

6. Operating limits (including environmental conditions);

All components within the load holding system are rated to the environmental conditions acceptable for the machine; see **Section 2.2**.

7. Indications and alarms;

There are no indicators or alarms to show that the Niftylift load holding system is functioning.

8. Muting and suspension of safety functions;

It is not possible to suspend the operation of the load holding system.

9. Control modes;

The load holding system has two modes of operation

- 1) Normal movements of the booms cause the system to constantly adjust the cylinders to maintain machine position and load holding.
- 2) Manual adjustment to recover the machine under emergency conditions.

10. Maintenance; Maintenance check lists;

Normal maintenance

- Removal of air from the hydraulic system if the product is left unused for long periods of time.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

If parts require replacement only replace the whole components such as hoses, hydraulic cylinders or load holding and over centre valve.

Do not attempt maintenance of hydraulic components i.e. replace seals or internal component.

Only Niftylift original and supplied parts shall be used.

12. Means for easy and safe trouble shooting;

Elevate the luffing booms and check that the cage remains level and the booms remain in their elevated position. If the cage does not remain level the system should be serviced by trained persons fully conversant with the function of the system.

13. Information explaining the applications for use relevant to the category to which reference is made;

Not applicable

14. Checking test intervals where relevant.

Check the operation of the load holding system to be made at the beginning of every duty cycle.

Operating & Safety Instructions

A7 INTERLOCKING OF TRAVEL CONTROLS

The interlocking of the control positions is PL b in accordance to with ISO 13849-1:2008 as required by BS EN 280:2013+A1 2015

1. The limits of the safety-related parts to the category selected and any fault exclusions;

The interlock to prevent simultaneous operation of the booms and travel controls consists of a PLC which checks all cage controls. The PLC which controls the outputs does not allow a booms and a drive function to operate simultaneously. **Proper maintenance and daily safety checks to be observed.**

2. The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

Maintenance must only be carried out by appropriately trained and competent persons, who are conversant with all modes of operation, speeds and characteristics of this model.

3. The effects of deviations from the specified performance on the safety function(s);

If the interlocking of the travel controls does not function as intended it is possible that the Niftylift may allow modes of operation that render it potentially dangerous.

If the controls do not remain independent in their operation, damage to the Niftylift, other equipment and properties, injury or loss of life of the operator and surrounding persons may be a risk.

4. Clear descriptions of the interfaces to the SRP/CS and protective devices;

The PLC that controls the boom or travel controls is located in the superstructure of the machine.

5. Response time

Loss of the boom functions is immediate as soon as a drive or steer function is selected.

6. Operating limits (including environmental conditions);

All components within the travel control interlock system are rated to the environmental conditions acceptable for the machine; see **Section 2.2**

7. Indications and alarms;

None.

8. Muting and suspension of safety functions;

None.

9. Control modes;

Either drive or booms operation modes are available.

10. Maintenance; Maintenance check lists;

Normal maintenance

- Visual check of all levers including the mechanical links from the levers to the valve spools.
- Ensure the smooth and uninterrupted operation of Drive controls.
- Check the loss of functions for all boom movements with the machine drive functions are operated and held to one end of travel. No boom functions should be available if any drive function is operated. Repeat for drive, but when doing so, be aware of the possibility of the machine moving as the control functions are checked. This should be performed in a clear, open area.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

Only Niftylift original and supplied parts shall be used.

12. Means for easy and safe trouble shooting;

To check the operation of the travel control interlock.

1. Power on the Niftylift and select the cage control location.
2. Allow the power circuits to cycle and ensure the machine is ready for the command signal.
3. Press the base green button and operate a boom function to raise.
4. At the same time, operate the trigger and steer the drive wheels in one direction or the other.
5. Observe that the boom control function is lost and does not return until the steer lever is released.
6. In a clear area, repeat for a drive forward/ drive backward lever function whilst operating a boom raise command.
7. Observe that the boom control function is lost and does not return until the drive lever is released.
8. Power off the Niftylift.

13. Information explaining the applications for use relevant to the category to which reference is made;

Not applicable

14. Checking test intervals where relevant.

Check the operation of the travel control interlock to be made at every service interval.

Operating & Safety Instructions**A8 EMERGENCY STOP SYSTEM**

The Emergency stop system is PL c/d in accordance to with BS EN ISO 13850:2015 as required by BS EN 280:2013+A1 2015.

1. The limits of the safety-related parts to the category selected and any fault exclusions;

There is a 2 channel input from both a base E-stop and a cage E-stop button into the base PLC. Each button operates a normally open and a normally closed switch contact. The failure mode of "Will not open" for the NC contact is excluded. If either E-stop button is pressed by the operator the booms enable valves V2 and V5 will de-energize disabling machine boom and drive functions.

Reasonably foreseeable misuse

2. The limits of the SRP/CS and any fault exclusion, for which, when essential for maintaining the selected category or categories and safety performance, appropriate information (e.g. for modification, maintenance and repair) shall be given to ensure the continued justification of the fault exclusion(s);

Do not alter, modify or disable in any way the controls, safety devices, interlocks or any other part of the machine.

Maintenance must only be carried on by appropriately trained and competent persons, who are conversant with all modes of operation, speeds and characteristics of this model.

3. The effects of deviations from the specified performance on the safety function(s);

If the Emergency stop system does not function as intended it is possible that the Niftylift may function when the E-stop is pressed.

If the product moves unexpectedly, damage to the Niftylift, other equipment and properties, injury or loss of life of the operator and surrounding persons may be a risk.

4. Clear descriptions of the interfaces to the SRP/CS and protective devices;

The Emergency stop system comprises of a primary devices the 2 Emergency stop button and a PLC, and protective devices, for example solenoid operated booms enable valves.

If the E-stop system is activated the system will not re-set until the button has been released.

5. Response time;

Operating the emergency stop is immediate

6. Operating limits (including environmental conditions);

All components within the emergency stop system are rated to the environmental conditions acceptable for the machine; see **Section 2.2**.

7. Indications and alarms;

When activated the emergency stop button remain visually in an operated position

8. Muting and suspension of safety functions;

If the E-stop button in the cage is operated the operator at the base may override this E-stop by changing the control location to the base using the key switch located at the base. The cage operator may then release the E-stop and operate it again to disable drive and boom functions.

9. Control modes;

The emergency stop system has no user controllable modes of operation.

10. Maintenance; Maintenance check lists;

Normal maintenance

- Visual check of connection wires.
- Check of power supply to verify it is correct.
- Check of the equipment correct operation, by simulating an emergency stop. See “Means for easy and safe trouble shooting”

The emergency stop will not normally require special maintenance.

Should special maintenance be required please observe the following precautions.

- Cut off power supply before every check or replacement.
- Do not weld on machine structure before removing power supply (positive and negative) and detaching boxes from vehicle frame or possible connections towards vehicle frame.
- Provide suitable mechanical protections for connection wires, paying particular attention for transducers.
- Do not place board, transducers or cabling close to sources of heat, electromagnetic interferences or power transmissions.
- Do not touch directly boards, transducers and boxes with flushing or degreaser fluids under pressure.
- Do not pierce the board box.
- Seal the box and/or the panel who contains the electronic board, to reveal any not authorized access or tampering.

11. Ease of accessibility and replacing of internal parts;

Replacement of parts should only be carried out by appropriately trained and competent persons.

If parts require replacement only replace the complete item such as the contact blocks, PLC, or Hydraulic valve block.

Do not attempt to open the main base PLC or replace components soldered to any PCB.

Do not attempt maintenance of hydraulic components i.e. replace seals or internal component.

Only Niftylift original and supplied parts shall be used.

12. Means for easy and safe trouble shooting;

To check the operation of the emergency stop system

1. Power on the Niftylift and select the base control location.
2. Allow the power circuits to cycle and ensure the machine is ready for the command signal.
3. Press the base green button and observe that the machine is ready to function with no load in the cage. (Machine runs, pump flow is available for machine functions.)
4. Select the Cage control position and mount into the cage.
5. Enable the cage controls and then press the cage green button or foot switch to enable the machine functions. (Machine runs, pump flow is available for machine operation.)

Operating & Safety Instructions

6. Press the cage emergency stop button. Press the green button or foot switch and observe that machine movements have been halted
7. Release the cage emergency stop button, switch the controls to the base and repeat for the base emergency stop button.
8. Power off the Niftylift.

13. Information explaining the applications for use relevant to the category to which reference is made;

Not applicable

14. Checking test intervals where relevant.

Check the operation of the emergency stop system to be made at the beginning of every duty cycle.

15. Proof testing

This two channel system must be proof tested to identify unrevealed failures every six months by a competent person with appropriate safety function experience.

Emergency stop system

Test 1

1. Identify the two solenoid valves maintaining the safety function for each channel using the machine electrical and hydraulic schematics – P27646 – V2 and V5.
2. Stow the machine and remove the coil from V2.
3. Attempt to operate the booms via the green button.
4. Fit the coil back onto V2.
5. Repeat steps 1-4 but for V5.

Pass criteria - If the booms do not operate the system is functioning correctly.

Fail criteria – If the booms move there is a previously undetected fault with the system and the Niftylift must not be used until this fault has been repaired.

Repair must be carried out by a competent person(s) with appropriate safety function experience.

niftylift